A/C OPERATION CHECK MODE [FULL-AUTO AIR CONDITIONER]

id0702c1881500

- The A/C operation check mode forcibly operates the output devices as shown in the operation check table regardless of the signals input to the climate control unit.
- During an A/C operation check mode operation, indication in the display panel and the illumination of the indicator light on the switches are automatically controlled.
- Determine the malfunctioning part by visual inspection, listening to the operation sound, placing a hand on the air vents, or checking that each transition is as indicated in the operation check table.

M-MDS display	Target part	Reference
Air Mix Actuator	• Air mix actuator • Air mix door	(See Air mix actuator)
Air conditioning compressor	• A/C compressor	(See A/C compressor)
Air Intake Actuator	• Air intake actuator • Air intake door	(See Air intake actuator)
Blower Motor Speed	• Blower motor	(See Blower motor)
Air Flow Mode Actuator	• Airflow mode actuator • Airflow mode door	(See Airflow mode actuator)
Illumination of All Indicator Lights	• Climate control unit	(See Indicator light)

Air mix actuator

1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. After the vehicle is identified, select the following items from the initial screen of the M-MDS.
   (1) Select the “Body”.
   (2) Select the “EATC Operation Check”.
4. Select the “Air Mix Actuator” from the screen menu.
5. Verify the A/C operation check mode according to the directions on the screen.
6. Select “Stop” to stop the A/C operation check. (See A/C operation check stop.)

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroste
1	**0 %**	VENT	5th	ON	FRESH	OFF
2	**100 %**					

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
1	Not Illuminated	Not illuminated	Illuminated
2			

Note

- After **approx. 4 s** have elapsed, the operation step moves to the next step.
- When the last step is finished, the operation is repeated from Step 1.
- To prevent super-cooling, the magnetic clutch turns off despite the A/C forced override.

A/C compressor

1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. After the vehicle is identified, select the following items from the initial screen of the M-MDS.
   (1) Select the “Body”.
   (2) Select the “EATC Operation Check”.
4. Select the “Air conditioning compressor” from the screen menu.
5. Verify the A/C operation check mode according to the directions on the screen.
6. Select “Stop” to stop the A/C operation check. (See A/C operation check stop.)

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroster
1	**0 %**	VENT	5th	ON	FRESH	OFF
2	**100 %**			OFF		

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
1	Not illuminated	Not illuminated	Illuminated
2			Not illuminated

Note
- After the following times have elapsed, the operation step moves to the next step.
  - Step 1: **Approx. 5 s**
  - Step 2: **Approx. 25 s**
- When the last step is finished, the operation is repeated from Step 1.

Air intake actuator
1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. After the vehicle is identified, select the following items from the initial screen of the M-MDS.
   (1) Select the “Body”.
   (2) Select the “EATC Operation Check”.
4. Select the “Air Intake Actuator” from the screen menu.
5. Verify the A/C operation check mode according to the directions on the screen.
6. Select “Stop” to stop the A/C operation check. (See A/C operation check stop.)

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroster
1	**0 %**	VENT	5th	ON	FRESH	OFF
2					RECIRCULATE	
3				OFF	FRESH	
4					RECIRCULATE	

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
1	Not illuminated	Not illuminated	Illuminated
2	Illuminated		
3	Not illuminated		Not illuminated
4	Illuminated		

Note
- After **approx. 4 s** have elapsed, the operation step moves to the next step.
- When the last step is finished, the operation is repeated from Step 1.
- To prevent super-cooling, the magnetic clutch turns off despite the A/C forced override.

Blower motor
1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. After the vehicle is identified, select the following items from the initial screen of the M-MDS.
   (1) Select the “Body”.
   (2) Select the “EATC Operation Check”.
4. Select the “Blower Motor Speed” from the screen menu.
5. Verify the A/C operation check mode according to the directions on the screen.
6. Select “Stop” to stop the A/C operation check. (See A/C operation check stop.)

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroster
1	**50 %**	VENT	OFF	OFF	FRESH	OFF
2			1st	ON		
3			3rd			
4			5th			
5			7th			

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
1	Not illuminated	Not illuminated	Not illuminated
2			Illuminated
3			
4			
5			

Note
- After **approx. 4 s** have elapsed, the operation step moves to the next step.
- When the last step is finished, the operation is repeated from Step 1.
- To prevent super-cooling, the magnetic clutch turns off despite the A/C forced override.

Airflow mode actuator
1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. After the vehicle is identified, select the following items from the initial screen of the M-MDS.
   (1) Select the “Body”.
   (2) Select the “EATC Operation Check”.
4. Select the “Airflow Mode Actuator” from the screen menu.
5. Verify the A/C operation check mode according to the directions on the screen.
6. Select “Stop” to stop the A/C operation check. (See A/C operation check stop.)

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroster
1	**50 %**	VENT	5th	ON	FRESH	OFF
2		BI-LEVEL				
3		HEAT				
4		DEF/HEAT				
5		DEFROSTER				

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
1	Not illuminated	Not illuminated	Illuminated
2			
3			
4			
5			

Note
- After **approx. 4 s** have elapsed, the operation step moves to the next step.
- When the last step is finished, the operation is repeated from Step 1.
- To prevent super-cooling, the magnetic clutch turns off despite the A/C forced override.

Indicator light
1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. After the vehicle is identified, select the following items from the initial screen of the M-MDS.
   (1) Select the “Body”.
   (2) Select the “EATC Operation Check”.
4. Select the “Illumination Of All Indicator Lights” from the screen menu.
5. Verify the A/C operation check mode according to the directions on the screen.
6. Select “Stop” to stop the A/C operation check. (See A/C operation check stop.)

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroster
—	**50 %**	VENT	OFF	OFF	FRESH	OFF

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
—	Illuminated	Illuminated	Illuminated

A/C operation check stop

1. If “Stop” is selected while the A/C operation check is operating, the A/C stops at the conditions shown in the table.

Operation

Step	Air mix actuator	Airflow mode actuator	Blower speed	Magnet clutch	Air intake actuator	Rear window defroster
—	**50 %**	VENT	OFF	OFF	FRESH	OFF

Indicator light

Step	Recirculate switch indicator light	Rear window defroster switch indicator light	A/C switch indicator light
—	Not illuminated	Not illuminated	Not illuminated