BLOWER MOTOR REMOVAL/INSTALLATION

id071100005900

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Remove the dashboard under cover. (See DASHBOARD UNDER COVER REMOVAL/INSTALLATION.)
3. Disconnect the blower motor connector.
4. Remove the screws.

