AIR FILTER INSPECTION

id071100360200

1. Remove the glove compartment. (See GLOVE COMPARTMENT REMOVAL/INSTALLATION.)
2. Remove the air filter. (See AIR FILTER REMOVAL/INSTALLATION.)
3. Verify that there is no damage, excessive dirt, or abnormal odor on the air filter.
   - If there is any malfunction, replace the air filter. (See AIR FILTER REMOVAL/INSTALLATION.)

Note
- The air filter cannot be reused by cleaning it with water or compressed air.