HEATER CORE INSPECTION

id071100801600

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Discharge the refrigerant. (See REFRIGERANT RECOVERY.)(See REFRIGERANT CHARGING.)
3. Drain the engine coolant. (See ENGINE COOLANT REPLACEMENT [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ENGINE COOLANT REPLACEMENT [SKYACTIV-D 1.5].)
4. Remove the dashboard. (See DASHBOARD REMOVAL.)(See DASHBOARD INSTALLATION.)
5. Remove the A/C unit. (See A/C UNIT REMOVAL/INSTALLATION.)
6. Remove the heater core. (See A/C UNIT DISASSEMBLY/ASSEMBLY.)
7. Inspect the heater core for damage, cracks, and water leakage.
   - If there is any malfunction, replace the heater core. (See A/C UNIT DISASSEMBLY/ASSEMBLY.)
8. Visually inspect the fins for bending.
   - If there is any bending, use the end of a flathead screwdriver to straighten the fins.
9. Visually inspect the heater hose for deformation.
   - Repair with pliers if there is deformation. If there is any malfunction, replace the heater core. (See A/C UNIT DISASSEMBLY/ASSEMBLY.)