EVAPORATOR TEMPERATURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER]

id0740a1801100

1. Remove the evaporator temperature sensor from the A/C unit. (See A/C UNIT DISASSEMBLY/ASSEMBLY.)