EVAPORATOR TEMPERATURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER]

id0740a2801100

1. Remove the evaporator temperature sensor from the A/C unit. (See A/C UNIT DISASSEMBLY/ASSEMBLY.)