CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1080600

CMDTC Self Test

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “All CMDTCs”.
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].)
8. Verify that no DTCs are displayed.

ODDTC Self Test

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “Modules”.
   (3) Select “RCM”.
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition off.
6. Switch the ignition ON (engine off or on) and wait for **11 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].)
8. Verify that no DTCs are displayed.