DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1080700

Caution

- **When DTCs not shown in the DTC table are displayed, perform the inspection for DTCs not shown in the DTC table. (See Inspection for DTCs not usually displayed so the related function is not equipped.)**

X: Applicable
−: Not applicable

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B0001:11	19		15	Driver-side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B0001:11/ B0001:12/ B0001:13/ B0001:19/ B0001:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B0001:12				Driver-side air bag module circuit short to power supply	—	—	C, D	×	
B0001:13				Driver-side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B0001:19				Short circuit to driver-side air bag module and other air bag module circuits	—	—	C, D	×	
B0001:1A				Driver-side air bag module circuit resistance low	—	—	C, D	×	
B0001:55	54		6	Configuration setting error (driver-side air bag module structural malfunction)	—	—	C, D	×	(See DTC B0001:55/ B0010:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
[B0002:11]	19		15	Driver-side air bag module (inflator No.2) circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B0002:12]				Driver-side air bag module (inflator No.2) circuit short to power supply	—	—	C, D	×	
[B0002:13]				Driver-side air bag module (inflator No.2) circuit open circuit or resistance high	—	—	C, D	×	
[B0002:19]				Short circuit to driver-side air bag module (inflator No.2) and other air bag module circuits	—	—	C, D	×	
[B0002:1A]				Driver-side air bag module (inflator No.2) circuit resistance low	—	—	C, D	×	
[B0002:55]	54		6	Configuration setting error (driver-side air bag module (inflator No.2) structural malfunction)	—	—	C, D	×	
B0003:53	—	Flashing	4	Operation (deployment) inhibited	—	—	C, D	×	(See DTC B0003:53 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B0010:11	21		14	Passenger-side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B0010:11/ B0010:12/ B0010:13/ B0010:19/ B0010:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B0010:12				Passenger-side air bag module circuit short to power supply	—	—	C, D	×	
B0010:13				Passenger-side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B0010:19				Short circuit to passenger-side air bag module and other air bag module circuits	—	—	C, D	×	
B0010:1A				Passenger-side air bag module circuit resistance low	—	—	C, D	×	
B0010:55	54		6	Configuration setting error (passenger-side air bag module structural malfunction)	—	—	C, D	×	(See DTC B0001:55/ B0010:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B0050:55	54		6	Configuration setting error (driver-side buckle switch structural malfunction)	—	—	C, D	×	(See DTC B0050:55/ B0052:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B0052:55				Configuration setting error (passenger-side buckle switch structural malfunction)	—	—	C, D	×	
B0094:11	42		10	Crash zone sensor circuit short to body ground	—	—	C, D	×	(See DTC B0094:11/ B0094:12/ B0094:29/ B0094:2B/ B0094:4A/ B0094:87/ B0094:96 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B0094:12				Crash zone sensor circuit short to power supply	—	—	C, D	×	
B0094:29				Crash zone sensor internal malfunction	—	—	C, D	×	
B0094:2B				Short circuit to crash zone sensor and other air bag sensor circuits	—	—	C, D	×	
B0094:4A				Crash zone sensor ID error	—	—	C, D	×	
B0094:87				Signal reception error from crash zone sensor	—	—	C, D	×	
B0094:96				Crash zone sensor internal malfunction	—	—	C, D	×	
B0094:55	54		6	Configuration setting error (crash zone sensor structural malfunction)	—	—	C, D	×	(See DTC B0094:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
[B00B5:11]	49		26	Seat track position sensor circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B00B5:12]				Seat track position sensor circuit short to power supply	—	—	C, D	×	
[B00B5:13]				Seat track position sensor circuit open	—	—	C, D	×	
[B00B5:1D]				Seat track position sensor circuit out of range	—	—	C, D	×	
[B00B5:2B]				Short circuit to seat track position sensor and other air bag sensor circuits	—	—	C, D	×	
[B00B5:55]	54		6	Configuration setting error (seat track position sensor structural malfunction)	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B00D2:01	—	—	—	Air bag system warning light malfunction	—	—	C, D	×	(See DTC B00D2:01 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B00D2:29				Invalid signal to air bag system warning light	—	—	C, D	×	(See DTC B00D2:29 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
[B00D5:01]	18		25	PAD indicator circuit open circuit or short to power supply	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B00D5:29]				PAD indicator communication error	—	—	C, D	×	
[B00D5:55]				Configuration setting error (indicator unit structural malfunction)	—	—	C, D	×	
B1011:95	58		7	SAS control module connectors are poorly connected	—	—	C, D	×	(See DTC B1011:95 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B10FD:11	43		13	Driver-side side air bag sensor circuit short to body ground	—	—	C, D	×	(See DTC B10FD:11/ B10FD:12/ B10FD:29/ B10FD:2B/ B10FD:4A/ B10FD:87/ B10FD:96 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B10FD:12				Driver-side side air bag sensor circuit short to power supply	—	—	C, D	×	
B10FD:29				Driver-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FD:2B				Short circuit to driver-side side air bag sensor and other air bag sensor circuits	—	—	C, D	×	
B10FD:4A				Driver-side side air bag sensor ID error	—	—	C, D	×	
B10FD:87				Signal reception error from driver-side side air bag sensor	—	—	C, D	×	
B10FD:96				Driver-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FD:55	54		6	Configuration setting error (driver-side side air bag sensor structural malfunction)	—	—	C, D	×	(See DTC B10FD:55/ B10FE:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B10FE:11	44		12	Passenger-side side air bag sensor circuit short to body ground	—	—	C, D	×	(See DTC B10FE:11/ B10FE:12/ B10FE:29/ B10FE:2B/ B10FE:4A/ B10FE:87/ B10FE:96 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B10FE:12				Passenger-side side air bag sensor circuit short to power supply	—	—	C, D	×	
B10FE:29				Passenger-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FE:2B				Short circuit to passenger-side side air bag sensor and other air bag sensor circuits	—	—	C, D	×	
B10FE:4A				Passenger-side side air bag sensor ID error	—	—	C, D	×	
B10FE:87				Signal reception error from passenger-side side air bag sensor	—	—	C, D	×	
B10FE:96				Passenger-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FE:55	54		6	Configuration setting error (passenger-side side air bag sensor structural malfunction)	—	—	C, D	×	(See DTC B10FD:55/ B10FE:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1126:11	22		20	Driver-side side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1126:11/ B1126:12/ B1126:13/ B1126:19/ B1126:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1126:12				Driver-side side air bag module circuit short to power supply	—	—	C, D	×	
B1126:13				Driver-side side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1126:19				Short circuit to driver-side side air bag module and other air bag module circuits	—	—	C, D	×	
B1126:1A				Driver-side side air bag module circuit resistance low	—	—	C, D	×	
B1126:55	54		6	Configuration setting error (driver-side side air bag module structural malfunction)	—	—	C, D	×	(See DTC B1126:55/ B1127:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1127:11	23		19	Passenger-side side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1127:11/ B1127:12/ B1127:13/ B1127:19/ B1127:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1127:12				Passenger-side side air bag module circuit short to power supply	—	—	C, D	×	
B1127:13				Passenger-side side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1127:19				Short circuit to passenger-side side air bag module and other air bag module circuits	—	—	C, D	×	
B1127:1A				Passenger-side side air bag module circuit resistance low	—	—	C, D	×	
B1127:55	54		6	Configuration setting error (passenger-side side air bag module structural malfunction)	—	—	C, D	×	(See DTC B1126:55/ B1127:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1128:11	24		22	Driver-side curtain air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1128:11/ B1128:12/ B1128:13/ B1128:19/ B1128:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1128:12				Driver-side curtain air bag module circuit short to power supply	—	—	C, D	×	
B1128:13				Driver-side curtain air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1128:19				Short circuit to driver-side curtain air bag module and other air bag module circuits	—	—	C, D	×	
B1128:1A				Driver-side curtain air bag module circuit resistance low	—	—	C, D	×	
B1128:55	54		6	Configuration setting error (driver-side curtain air bag module structural malfunction)	—	—	C, D	×	(See DTC B1128:55/ B1129:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1129:11	25		21	Passenger-side curtain air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1129:11/ B1129:12/ B1129:13/ B1129:19/ B1129:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1129:12				Passenger-side curtain air bag module circuit short to power supply	—	—	C, D	×	
B1129:13				Passenger-side curtain air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1129:19				Short circuit to passenger-side curtain air bag module and other air bag module circuits	—	—	C, D	×	
B1129:1A				Passenger-side curtain air bag module circuit resistance low	—	—	C, D	×	
B1129:55	54		6	Configuration setting error (passenger-side curtain air bag module structural malfunction)	—	—	C, D	×	(See DTC B1128:55/ B1129:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1193:00	13		3	SAS control module operation (deployment)	—	—	C, D	×	(See DTC B1193:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1206:00	—	—	—	SAS control module operation (deployment) (fuel cut signal output)	—	—	C, D	×	(See DTC B1206:00/ B143A:00/ U2107:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1211:11	38		18	Driver-side pre-tensioner seat belt circuit short to body ground	—	—	C, D	×	(See DTC B1211:11/ B1211:12/ B1211:13/ B1211:19/ B1211:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1211:12				Driver-side pre-tensioner seat belt circuit short to power supply	—	—	C, D	×	
B1211:13				Driver-side pre-tensioner seat belt circuit open circuit or resistance high	—	—	C, D	×	
B1211:19				Short circuit to driver-side pre-tensioner seat belt and other air bag module circuits	—	—	C, D	×	
B1211:1A				Driver-side pre-tensioner seat belt circuit resistance low	—	—	C, D	×	
B1211:55	54		6	Configuration setting error (driver-side pre-tensioner seat belt structural malfunction)	—	—	C, D	×	(See DTC B1211:55, B1214:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1214:11	39		17	Passenger-side pre-tensioner seat belt circuit short to body ground	—	—	C, D	×	(See DTC B1214:11/ B1214:12/ B1214:13/ B1214:19/ B1214:1A [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1214:12				Passenger-side pre-tensioner seat belt circuit short to power supply	—	—	C, D	×	
B1214:13				Passenger-side pre-tensioner seat belt circuit open circuit or resistance high	—	—	C, D	×	
B1214:19				Short circuit to passenger-side pre-tensioner seat belt and other air bag module circuits	—	—	C, D	×	
B1214:1A				Passenger-side pre-tensioner seat belt circuit resistance low	—	—	C, D	×	
B1214:55	54		6	Configuration setting error (passenger-side pre-tensioner seat belt structural malfunction)	—	—	C, D	×	(See DTC B1211:55, B1214:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
[B1226:02]	36		11	Signal reception error from driver or passenger-side pressure sensor	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1226:29]				Driver-side pressure sensor internal malfunction	—	—	C, D	×	
[B1226:4A]				Driver-side pressure sensor ID error	—	—	C, D	×	
[B1226:87]				Signal reception error from driver-side pressure sensor	—	—	C, D	×	
[B1226:96]				Driver-side pressure sensor internal malfunction	—	—	C, D	×	
[B1226:55]	54		6	Configuration setting error (driver-side pressure sensor structural malfunction)	—	—	C, D	×	
[B1227:29]	37		10	Passenger-side pressure sensor internal malfunction	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1227:4A]				Passenger-side pressure sensor ID error	—	—	C, D	×	
[B1227:87]				Signal reception error from passenger-side pressure sensor	—	—	C, D	×	
[B1227:96]				Passenger-side pressure sensor internal malfunction	—	—	C, D	×	
[B1227:55]	54		6	Configuration setting error (passenger-side pressure sensor structural malfunction)	—	—	C, D	×	
[B1228:11]	35		16	Lap pre-tensioner seat belt circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1228:12]				Lap pre-tensioner seat belt circuit short to power supply	—	—	C, D	×	
[B1228:13]				Lap pre-tensioner seat belt circuit open circuit or resistance high	—	—	C, D	×	
[B1228:19]				Short circuit to lap pre-tensioner seat belt and other air bag module circuits	—	—	C, D	×	
[B1228:1A]				Lap pre-tensioner seat belt circuit resistance low	—	—	C, D	×	
[B1228:55]	54		6	Configuration setting error (lap pre-tensioner seat belt structural malfunction)	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
[B1410:11]	33		24	Rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1410:12]				Rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit short to power supply	—	—	C, D	×	
[B1410:13]				Rear lap pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit open circuit or resistance high	—	—	C, D	×	
[B1410:19]				Short circuit to rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) and other air bag module circuits	—	—	C, D	×	
[B1410:1A]				Rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit resistance low	—	—	C, D	×	
[B1410:55]	54		6	Configuration setting error (rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) structural malfunction)	—	—	C, D	×	
[B1412:11]	32		23	Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1412:12]				Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit short to power supply	—	—	C, D	×	
[B1412:13]				Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit open circuit or resistance high	—	—	C, D	×	
[B1412:19]				Short circuit to rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) and other air bag module circuits	—	—	C, D	×	
[B1412:1A]				Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit resistance low	—	—	C, D	×	
[B1412:55]	54		6	Configuration setting error (rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) structural malfunction)	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
[B1417:11]	41		8	Passenger-side crash zone sensor circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1417:12]				Passenger-side crash zone sensor circuit short to power supply	—	—	C, D	×	
[B1417:29]				Passenger-side cash zone sensor internal malfunction	—	—	C, D	×	
[B1417:2B]				Passenger-side crash zone sensor circuit short to other air bag sensor circuit	—	—	C, D	×	
[B1417:4A]				Passenger-side crash zone sensor ID error	—	—	C, D	×	
[B1417:87]				Signal reception error from passenger-side crash zone sensor	—	—	C, D	×	
[B1417:96]				Passenger-side cash zone sensor internal malfunction	—	—	C, D	×	
[B1417:55]	54		6	Configuration setting error (passenger-side crash zone sensor structural malfunction)	—	—	C, D	×	
B143A:00	—	—	—	SAS control module operation (deployment) signal output	—	—	C, D	×	(See DTC B1206:00/ B143A:00/ U2107:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B1485:55	54		6	Configuration setting error (occupancy sensor structural malfunction)	—	—	C, D	×	(See DTC B1485:55 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
[B1D74:55]	54		6	Configuration setting error (PAD switch structural malfunction)	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1D75:55]	54		6	Configuration setting error (PAD switch structural malfunction)	—	—	C, D	×	
[B1D75:62]	56		27	PAD switch circuit open circuit or short to body ground	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
C0061:29	—	—	—	Low-G sensor (lateral-G) in SAS control module (internal circuit disabled)	—	—	C, D	×	(See DTC C0061:29/ C0062:29/ C0063:29 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
C0062:29				Low-G sensor (forward-G) in SAS control module (internal circuit disabled)	—	—	C, D	×	
C0063:29				Yaw rate sensor in SAS control module (internal circuit disabled)	—	—	C, D	×	
U0001:88	—	Continuously illuminated	1	Module communication error (HS-CAN)	—	—	C, D	×	(See DTC U0001:88/ U0155:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
U0100:00	14		5	PCM communication error or invalid value reception	—	—	C, D	×	(See DTC U0100:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
U0155:00	14		5	Communication error with instrument cluster	—	—	C, D	×	(See DTC U0001:88/ U0155:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
U2100:00	—	Flashing	4	Configuration not set	—	—	C, D	×	(See DTC U2100:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
U2107:00	—	—	—	SAS control module operation (deployment) signal output	—	—	C, D	×	(See DTC B1206:00/ B143A:00/ U2107:00 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
U3000:49	12		2	SAS control module internal malfunction	—	—	C, D	×	(See DTC U3000:49 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
	—	Continuously illuminated	1						

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
U3003:16	—	Continuously illuminated	1	SAS control module power supply voltage decreases (**less than 8 V**)	—	—	C, D	×	(See DTC U3003:16/ U3003:17 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
U3003:17				SAS control module power supply voltage increases (**16 V or more**)	—	—	C, D	×	

*1 : C: CMDTC self test, D: ODDTC self test
[ ] : DTCs do not usually display because the related function is not equipped.

Inspection for DTCs not usually displayed so the related function is not equipped
Diagnostic procedure

Step	Inspection		Action
1	**INSPECT FOR ANY DTC DISPLAYED SIMULTANEOUSLY** • Is any DTC not within [ ] in the DTC table displayed simultaneously?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].)
		No	Go to the next step.
2	**VERIFY IF MALFUNCTION CAUSED BY TEMPORARY MALFUNCTION IN SAS CONTROL MODULE** • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs displayed?	Yes	Go to the next step.
		No	DTC troubleshooting completed.
3	**VERIFY IF MALFUNCTION CAUSED BY CONFIGURATION ERROR** • Perform the SAS control module configuration using the M-MDS. (See SAS CONTROL MODULE CONFIGURATION (USING AS-BUILT DATA) [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs displayed?	Yes	Re-perform the configuration, then perform the DTC inspection. • If the same DTC is displayed, replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].)
		No	DTC troubleshooting completed.