PID/DATA MONITOR TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1081000

PID	Unit/Condition	Data contents	SAS control module terminal
AB_WL (Air bag system warning light status)	Lamp_Off/ Lamp_On/ Plant_Mode/ Unknown	• Air bag system warning light off: Lamp_Off • Air bag system warning light on: Lamp_On • Air bag system warning light status: Plant_Mode • Air bag system warning light status: Unknown	3Q, 3S
D_SP_S_FLT (Seat track position sensor malfunction status)	**Note** • Displays in the M-MDS but it does not operate.		
D_SP_S_ST (Seat track position sensor status)	**Note** • Displays in the M-MDS but it does not operate.		
OCS_DTC_CLR (Seat weight sensor DTC cleared status)	**Note** • Displays in the M-MDS but it does not operate.		
P_OCS_ST (Seat weight sensor status)	**Note** • Displays in the M-MDS but it does not operate.		
P_SEAT_M_S (Occupancy sensor)	Off/On	• Not occupant seated in passenger-side front seat: Off • Occupant seated in passenger-side front seat: On	2AA
PAD_SW (Passenger air bag deactibation (PAD) switch status)	**Note** • Displays in the M-MDS but it does not operate.		
PAD_SW_FLT (Passenger air bag deactibation (PAD) switch malfunction status)	**Note** • Displays in the M-MDS but it does not operate.		
RES_C_AB_D (Driver-side curtain air bag module resistance nominal)	ohm	Continuous: 0.81–6.42 ohms	1W, 1U
RES_C_AB_P (Passenger-side curtain air bag module resistance nominal)	ohm	Continuous: 0.81–6.42 ohms	1AA, 1Z
RES_F_AB1_D (Driver-side air bag module (inflatorNo.1) resistance nominal)	ohm	Continuous: 0.99–6.42 ohms	3C, 3G
RES_F_AB1_P (Passenger-side air bag module (inflatorNo.1) resistance nominal)	ohm	Continuous: 0.81–6.42 ohms	3K, 3N
RES_F_AB2_D (Driver-side air bag module (inflatorNo.2) resistance nominal)	**Note** • Displays in the M-MDS but it does not operate.		
RES_F_AB2_P (Passenger-side air bag module (inflator No.2) resistance nominal)	**Note** • Displays in the M-MDS but it does not operate.		
RES_S_AB_D (Driver-side side air bag module resistance nominal)	ohm	Continuous: 0.81–9.85 ohms	1C, 1G

PID	Unit/Condition	Data contents	SAS control module terminal
RES_S_AB_P (Passenger-side side air bag module resistance nominal)	ohm	Continuous: 0.81–9.85 ohms	1K, 1N
RES_SB_LP_D (Driver-side lap pre-tensioner seat belt resistance nominal)	**Note** • Displays in the M-MDS but it does not operate.		
RES_SB_LP_P (Passenger-side lap pre-tensioner seat belt resistance nominal)	**Note** • Displays in the M-MDS but it does not operate.		
RES_SB_P_D (Driver-side pre-tensioner seat belt resistance nominal)	ohm	Continuous: 0.81–6.42 ohms	2C, 2G
RES_SB_P_P (Passenger-side pre-tensioner seat belt resistance nominal)	ohm	Continuous: 0.81–6.42 ohms	2K, 2N
RES_R_PR_D (Rear pre-tensioner seat belt status)	**Note** • Displays in the M-MDS but it does not operate.		
RES_R_PR_P (Rear pre-tensioner seat belt status)	**Note** • Displays in the M-MDS but it does not operate.		
PCD_A (Poorly connected detector bar terminal voltage nominal (SAS control module connector A))	mV	• Normal connected: 270.9 mV or less • Poor connected: 3173.4 mV or more	1a, 1b
PCD_B (Poorly connected detector bar terminal voltage nominal (SAS control module connector B))	mV	• Normal connected: 270.9 mV or less • Poor connected: 3173.4 mV or more	2a, 2b
PCD_C (Poorly connected detector bar terminal voltage nominal (SAS control module connector C))	mV	• Normal connected: 270.9 mV or less • Poor connected: 3173.4 mV or more	3a, 3b
SEAT_B_D (Driver-side buckle switch status)	Unbuckled/ Buckled	• Driver-side front seat belt fastened (Driver-side buckle switch off): Buckled • Driver-side front seat belt not fastened (Driver-side buckle switch on): Unbuckled	2U
SEAT_B_P (Passenger-side buckle switch status)	Unbuckled/ Buckled	• Passenger-side front seat belt fastened (Passenger-side buckle switch off): Buckled • Passenger-side front seat belt not fastened (Passenger-side buckle switch on): Unbuckled	2W
VPWR_IGA (SAS control module power voltage)	V	Ignition is switched ON: IG1 voltage	2AD