DTC B1193:00 [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1822000

System malfunction location	• SAS control module operation (deployment)
Detection condition	**Warning** **• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.** • SAS control module operates (deploys) (air bag module or pre-tensioner seat belt)
Fail-safe function	Not applicable
Possible cause	• SAS control module operation (deployment) • SAS control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

ACTION
• Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].)