DTC C0061:29/C0062:29/C0063:29 [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1847700

System malfunction location	• C0061:29: Low-G sensor (lateral-G) in SAS control module (internal circuit disabled) • C0062:29: Low-G sensor (forward-G) in SAS control module (internal circuit disabled) • C0063:29: Yaw rate sensor in SAS control module (internal circuit disabled)
Detection condition	**Warning** **• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.** • SAS control module internal sensor has a malfunction
Fail-safe function	Not applicable
Possible cause	SAS control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**PERFORM SAS CONTROL MODULE DTC INSPECTION** • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs present?	Yes	Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].)
		No	DTC troubleshooting completed.