DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM]

id0802b2080700

Caution

- **When DTCs not shown in the DTC table are displayed, perform the inspection for DTCs not shown in the DTC table. (See Inspection for DTCs not usually displayed so the related function is not equipped.)**

X: Applicable
−: Not applicable

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light		Priority ranking						
	Flashing pattern								
B0001:11	19		15	Driver-side air bag module (inflator No.1) circuit short to body ground	—	—	C, D	×	(See DTC B0001:11/ B0001:12/ B0001:13/ B0001:19/ B0001:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0001:12				Driver-side air bag module (inflator No.1) circuit short to power supply	—	—	C, D	×	
B0001:13				Driver-side air bag module (inflator No.1) circuit open circuit or resistance high	—	—	C, D	×	
B0001:19				Short circuit to driver-side air bag module (inflator No.1) and other air bag module circuits	—	—	C, D	×	
B0001:1A				Driver-side air bag module (inflator No.1) circuit resistance low	—	—	C, D	×	
B0001:55	54		6	Configuration setting error (driver-side air bag module (inflator No.1) structural malfunction)	—	—	C, D	×	(See DTC B0001:55/ B0010:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0002:11	19		15	Driver-side air bag module (inflator No.2) circuit short to body ground	—	—	C, D	×	(See DTC B0002:11/ B0002:12/ B0002:13/ B0002:19/ B0002:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0002:12				Driver-side air bag module (inflator No.2) circuit short to power supply	—	—	C, D	×	
B0002:13				Driver-side air bag module (inflator No.2) circuit open circuit or resistance high	—	—	C, D	×	
B0002:19				Short circuit to driver-side air bag module (inflator No.2) and other air bag module circuits	—	—	C, D	×	
B0002:1A				Driver-side air bag module (inflator No.2) circuit resistance low	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B0002:55	54		6	Configuration setting error (driver-side air bag module (inflator No.2) structural malfunction)	—	—	C, D	×	(See DTC B0002:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0003:53	—	Flashing	4	Operation (deployment) inhibited	—	—	C, D	×	(See DTC B0003:53 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0010:11	21		14	Passenger-side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B0010:11/ B0010:12/ B0010:13/ B0010:19/ B0010:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0010:12				Passenger-side air bag module circuit short to power supply	—	—	C, D	×	
B0010:13				Passenger-side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B0010:19				Short circuit to passenger-side air bag module and other air bag module circuits	—	—	C, D	×	
B0010:1A				Passenger-side air bag module (inflator circuit resistance low	—	—	C, D	×	
B0010:55	54		6	Configuration setting error (passenger-side air bag module (inflator structural malfunction)	—	—	C, D	×	(See DTC B0001:55/ B0010:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0050:55	54		6	Configuration setting error (driver-side buckle switch (structural malfunction)	—	—	C, D	×	(See DTC B0050:55/ B0052:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0052:55				Configuration setting error (passenger-side buckle switch (structural malfunction)	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B0094:11	42		9	Crash zone sensor circuit short to body ground	—	—	C, D	×	(See DTC B0094:11/ B0094:12/ B0094:29/ B0094:2B/ B0094:4A/ B0094:87/ B0094:96 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B0094:12				Crash zone sensor circuit short to power supply	—	—	C, D	×	
B0094:29				Crash zone sensor internal malfunction	—	—	C, D	×	
B0094:2B				Crash zone sensor circuit short to other air bag sensor circuit	—	—	C, D	×	
B0094:4A				Crash zone sensor ID error	—	—	C, D	×	
B0094:87				Signal reception error from crash zone sensor	—	—	C, D	×	
B0094:96				Crash zone sensor internal malfunction	—	—	C, D	×	
B0094:55	54		6	Configuration setting error (crash zone sensor structural malfunction)	—	—	C, D	×	(See DTC B0094:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B00B5:11	49		26	Seat track position sensor circuit short to body ground	—	—	C, D	×	(See DTC B00B5:11/ B00B5:12/ B00B5:13/ B00B5:1D/ B00B5:2B [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B00B5:12				Seat track position sensor circuit short to power supply	—	—	C, D	×	
B00B5:13				Seat track position sensor circuit open	—	—	C, D	×	
B00B5:1D				Seat track position sensor circuit out of range	—	—	C, D	×	
B00B5:2B				Short circuit to seat track position sensor and other air bag sensor circuits	—	—	C, D	×	
B00B5:55	54		6	Configuration setting error (seat track position sensor structural malfunction)	—	—	C, D	×	(See DTC B00B5:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B00D2:01	—	—	—	Air bag system warning light malfunction	—	—	C, D	×	(See DTC B00D2:01 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B00D2:29	—	—	—	Invalid signal to air bag system warning light	—	—	C, D	×	(See DTC B00D2:29 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B00D5:01	18		25	PAD indicator circuit open circuit or short to power supply	—	—	C, D	×	(See DTC B00D5:01/ B00D5:29 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B00D5:29				PAD indicator communication error	—	—	C, D	×	
B00D5:55				Configuration setting error (indicator unit structural malfunction)	—	—	C, D	×	(See DTC B00D5:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1011:95	58		7	SAS control module connectors are poorly connected	—	—	C, D	×	(See DTC B1011:95 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B10FD:11	43		13	Driver-side side air bag sensor circuit short to body ground	—	—	C, D	×	(See DTC B10FD:11/ B10FD:12/ B10FD:29/ B10FD:2B/ B10FD:4A/ B10FD:87/ B10FD:96 [STANDARD DEPLOYMENT CONTROL SYSTEM].)
B10FD:12				Driver-side side air bag sensor circuit short to power supply	—	—	C, D	×	
B10FD:29				Driver-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FD:2B				Driver-side side air bag sensor circuit short to other air bag sensor circuit	—	—	C, D	×	
B10FD:4A				Driver-side side air bag sensor ID error	—	—	C, D	×	
B10FD:87				Signal reception error from driver-side side air bag sensor	—	—	C, D	×	
B10FD:96				Driver-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FD:55	54		6	Configuration setting error (driver-side side air bag sensor structural malfunction)	—	—	C, D	×	(See DTC B10FD:55/ B10FE:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B10FE:11	44		12	Passenger-side side air bag sensor circuit short to body ground	—	—	C, D	×	(See DTC B10FE:11/ B10FE:12/ B10FE:29/ B10FE:2B/ B10FE:4A/ B10FE:87/ B10FE:96 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B10FE:12				Passenger-side side air bag sensor circuit short to power supply	—	—	C, D	×	
B10FE:29				Passenger-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FE:2B				Passenger-side side air bag sensor circuit short to other air bag sensor circuit	—	—	C, D	×	
B10FE:4A				Signal reception error from passenger-side side air bag sensor	—	—	C, D	×	
B10FE:87				Signal reception error from passenger-side side air bag sensor ID error	—	—	C, D	×	
B10FE:96				Passenger-side side air bag sensor internal malfunction	—	—	C, D	×	
B10FE:55	54		6	Configuration setting error (passenger-side side air bag sensor structural malfunction)	—	—	C, D	×	(See DTC B10FD:55/ B10FE:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1126:11	22		20	Driver-side side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1126:11/ B1126:12/ B1126:13/ B1126:19/ B1126:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1126:12				Driver-side side air bag module circuit short to power supply	—	—	C, D	×	
B1126:13				Driver-side side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1126:19				Short circuit to driver-side side air bag module and other air bag module circuits	—	—	C, D	×	
B1126:1A				Driver-side side air bag module circuit resistance low	—	—	C, D	×	
B1126:55	54		6	Configuration setting error (driver-side side air bag module structural malfunction)	—	—	C, D	×	(See DTC B1126:55/ B1127:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1127:11	23		19	Passenger-side side air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1127:11/ B1127:12/ B1127:13/ B1127:19/ B1127:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1127:12				Passenger-side side air bag module circuit short to power supply	—	—	C, D	×	
B1127:13				Passenger-side side air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1127:19				Short circuit to passenger-side side air bag module and other air bag module circuits	—	—	C, D	×	
B1127:1A				Passenger-side side air bag module circuit resistance low	—	—	C, D	×	
B1127:55	54		6	Configuration setting error (passenger-side side air bag module structural malfunction)	—	—	C, D	×	(See DTC B1126:55/ B1127:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1128:11	24		22	Driver-side curtain air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1128:11/ B1128:12/ B1128:13/ B1128:19/ B1128:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1128:12				Driver-side curtain air bag module circuit short to power supply	—	—	C, D	×	
B1128:13				Driver-side curtain air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1128:19				Short circuit to driver-side curtain air bag module and other air bag module circuits	—	—	C, D	×	
B1128:1A				Driver-side curtain air bag module circuit resistance low	—	—	C, D	×	
B1128:55	54		6	Configuration setting error (driver-side curtain air bag module structural malfunction)	—	—	C, D	×	(See DTC B1128:55/ B1129:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1129:11	25		21	Passenger-side curtain air bag module circuit short to body ground	—	—	C, D	×	(See DTC B1129:11/ B1129:12/ B1129:13/ B1129:19/ B1129:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1129:12				Passenger-side curtain air bag module circuit short to power supply	—	—	C, D	×	
B1129:13				Passenger-side curtain air bag module circuit open circuit or resistance high	—	—	C, D	×	
B1129:19				Short circuit to passenger-side curtain air bag module and other air bag module circuits	—	—	C, D	×	
B1129:1A				Passenger-side curtain air bag module circuit resistance low	—	—	C, D	×	
B1129:55	54		6	Configuration setting error (passenger-side curtain air bag module structural malfunction)	—	—	C, D	×	(See DTC B1128:55/ B1129:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1193:00	13		3	SAS control module operation (deployment)	—	—	C, D	×	(See DTC B1193:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1206:00	—	—	—	SAS control module operation (deployment) (fuel cut signal output)	—	—	C, D	×	(See DTC B1206:00/ B143A:00/ U2107:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1211:11	38		18	Driver-side pre-tensioner seat belt circuit short to body ground	—	—	C, D	×	(See DTC B1211:11/ B1211:12/ B1211:13/ B1211:19/ B1211:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1211:12				Driver-side pre-tensioner seat belt circuit short to power supply	—	—	C, D	×	
B1211:13				Driver-side pre-tensioner seat belt circuit open circuit or resistance high	—	—	C, D	×	
B1211:19				Short circuit to driver-side pre-tensioner seat belt and other air bag module circuits	—	—	C, D	×	
B1211:1A				Driver-side pre-tensioner seat belt circuit resistance low	—	—	C, D	×	
B1211:55	54		6	Configuration setting error (driver-side pre-tensioner seat belt structural malfunction)	—	—	C, D	×	(See DTC B1211:55, B1214:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1214:11	39		17	Passenger-side pre-tensioner seat belt circuit short to body ground	—	—	C, D	×	(See DTC B1214:11/ B1214:12/ B1214:13/ B1214:19/ B1214:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1214:12				Passenger-side pre-tensioner seat belt circuit short to power supply	—	—	C, D	×	
B1214:13				Passenger-side pre-tensioner seat belt circuit open circuit or resistance high	—	—	C, D	×	
B1214:19				Short circuit to passenger-side pre-tensioner seat belt and other air bag module circuits	—	—	C, D	×	
B1214:1A				Passenger-side pre-tensioner seat belt circuit resistance low	—	—	C, D	×	
B1214:55	54		6	Configuration setting error (passenger-side pre-tensioner seat belt structural malfunction)	—	—	C, D	×	(See DTC B1211:55, B1214:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1226:02	36		11	Signal reception error from driver or passenger-side pressure sensor	—	—	C, D	×	(See DTC B1226:02 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1226:29				Driver-side pressure sensor internal malfunction	—	—	C, D	×	(See DTC B1226:29/ B1226:4A/ B1226:87/ B1226:96 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1226:4A				Driver-side pressure sensor ID mismatch	—	—	C, D	×	
B1226:87				Driver-side pressure sensor circuit open	—	—	C, D	×	
B1226:96				Driver-side pressure sensor internal malfunction	—	—	C, D	×	
B1226:55	54		6	Configuration setting error (driver-side pressure sensor structural malfunction)	—	—	C, D	×	(See DTC B1226:55, B1227:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1227:29	37		10	Passenger-side pressure sensor internal malfunction	—	—	C, D	×	DTC B1227:29/ B1227:4A/ B1227:87/ B1227:96 [TWO-STEP DEPLOYMENT CONTROL SYSTEM]
B1227:4A				Passenger-side pressure sensor ID mismatch	—	—	C, D	×	
B1227:87				Passenger-side pressure sensor circuit open	—	—	C, D	×	
B1227:96				Passenger-side pressure sensor internal malfunction	—	—	C, D	×	
B1227:55	54		6	Configuration setting error (passenger-side pressure sensor structural malfunction)	—	—	C, D	×	(See DTC B1226:55, B1227:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
[B1228:11]	35		16	Lap pre-tensioner seat belt circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1228:12]				Lap pre-tensioner seat belt circuit short to power supply	—	—	C, D	×	
[B1228:13]				Lap pre-tensioner seat belt circuit open circuit or resistance high	—	—	C, D	×	
[B1228:19]				Short circuit to lap pre-tensioner seat belt and other air bag module circuits	—	—	C, D	×	
[B1228:1A]				Lap pre-tensioner seat belt circuit resistance low	—	—	C, D	×	
[B1228:55]	54		6	Configuration setting error (lap pre-tensioner seat belt structural malfunction)	—	—	C, D	×	
B1410:11	33		24	Rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit short to body ground	—	—	C, D	×	(See DTC B1410:11/ B1410:12/ B1410:13/ B1410:19/ B1410:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1410:12				Rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit short to power supply	—	—	C, D	×	
B1410:13				Rear lap pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit open circuit or resistance high	—	—	C, D	×	
B1410:19				Short circuit to rear pre-tensioner seat belt (L.H.D.:LH/R.H.D.:RH) and other air bag module circuits	—	—	C, D	×	
B1410:1A				Rear pre-tensioner seat belt (L.H.D.:LH/ R.H.D.:RH) circuit resistance low	—	—	C, D	×	
B1410:55	54		6	Configuration setting error (rear pre-tensioner seat belt (L.H.D.:LH/R.H.D.:RH) structural malfunction)	—	—	C, D	×	(See DTC B1410:55/ B1412:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B1412:11	32		23	Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit short to body ground	—	—	C, D	×	(See DTC B1412:11/ B1412:12/ B1412:13/ B1412:19/ B1412:1A [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1412:12				Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit short to power supply	—	—	C, D	×	
B1412:13				Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit open circuit or resistance high	—	—	C, D	×	
B1412:19				Short circuit to rear pre-tensioner seat belt (L.H.D.:RH/R.H.D.:LH) and other air bag module circuits	—	—	C, D	×	
B1412:1A				Rear pre-tensioner seat belt (L.H.D.:RH/ R.H.D.:LH) circuit resistance low	—	—	C, D	×	
B1412:55	54		6	Configuration setting error (rear pre-tensioner seat belt (L.H.D.:RH/R.H.D.:LH) structural malfunction)	—	—	C, D	×	(See DTC B1410:55/ B1412:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
[B1417:11]	41		8	Passenger-side crash zone sensor circuit short to body ground	—	—	C, D	×	(See Inspection for DTCs not usually displayed so the related function is not equipped.)
[B1417:12]				Passenger-side crash zone sensor circuit short to power supply	—	—	C, D	×	
[B1417:29]				Passenger-side cash zone sensor internal malfunction	—	—	C, D	×	
[B1417:2B]				Passenger-side crash zone sensor circuit short to other air bag sensor circuit	—	—	C, D	×	
[B1417:4A]				Passenger-side crash zone sensor ID error	—	—	C, D	×	
[B1417:87]				Signal reception error from passenger-side crash zone sensor	—	—	C, D	×	
[B1417:96]				Passenger-side cash zone sensor internal malfunction	—	—	C, D	×	
[B1417:55]	54		6	Configuration setting error (passenger-side crash zone sensor structural malfunction)	—	—	C, D	×	

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
B143A:00	—	—	—	SAS control module operation (deployment) signal output	—	—	C, D	×	(See DTC B1206:00/ B143A:00/ U2107:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1485:55	54		6	Configuration setting error (occupancy sensor structural malfunction)	—	—	C, D	×	(See DTC B1485:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1D74:55	54		6	Configuration setting error (PAD switch structural malfunction)	—	—	C, D	×	(See DTC B1D74:55/ B1D75:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1D75:55	54		6	Configuration setting error (PAD switch structural malfunction)	—	—	C, D	×	(See DTC B1D74:55/ B1D75:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
B1D75:62	56		27	PAD switch circuit open circuit or short to body ground	—	—	C, D	×	(See DTC B1D75:62 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
C0061:29	—	—	—	Low-G sensor (lateral-G) in SAS control module (internal circuit disabled)	—	—	C, D	×	(See DTC C0061:29/ C0062:29/ C0063:29 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
C0062:29				Low-G sensor (forward-G) in SAS control module (internal circuit disabled)	—	—	C, D	×	
C0063:29				Yaw rate sensor in SAS control module (internal circuit disabled)	—	—	C, D	×	
U0001:88	—	Continuously illuminated	1	Module communication error (HS-CAN)	—	—	C, D	×	(See DTC U0001:88/ U0155:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
U0100:00	14		5	PCM Communication error or invalid value reception	—	—	C, D	×	(See DTC U0100:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)

DTC				System malfunction location	Fail-safe function	Drive cycle	Self test type* 1	Memory function	Page
M-MDS display	Air bag system warning light								
	Flashing pattern		Priority ranking						
U0155:00	14		5	Communication error with instrument cluster	—	—	C, D	×	(See DTC U0001:88/ U0155:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
U2100:00	—	Flashing	4	Configuration not set	—	—	C, D	×	(See DTC U2100:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
U2107:00	—	—	—	SAS control module operation (deployment) signal output	—	—	C, D	×	(See DTC B1206:00/ B143A:00/ U2107:00 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
U3000:49	—	Continuously illuminated	1	SAS control module internal malfunction	—	—	C, D	×	(See DTC U3000:49 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
	12		2						
U3003:16	—	Continuously illuminated	1	SAS control module power supply voltage decreases (**less than 8 V**)	—	—	C, D	×	(See DTC U3003:16/ U3003:17 [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
U3003:17				SAS control module power supply voltage increases (**16 V or more**)	—	—	C, D	×	

*1 : C: CMDTC self test, D: ODDTC self test
[ ] : DTCs do not usually display because the related function is not equipped.

Inspection for DTCs not usually displayed so the related function is not equipped
Diagnostic procedure

Step	Inspection		Action
1	**INSPECT FOR ANY DTC DISPLAYED SIMULTANEOUSLY** • Is any DTC not within [ ] in the DTC table displayed simultaneously?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		No	Go to the next step.
2	**VERIFY IF MALFUNCTION CAUSED BY TEMPORARY MALFUNCTION IN SAS CONTROL MODULE** • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs displayed?	Yes	Go to the next step.
		No	DTC troubleshooting completed.

Step	Inspection		Action
3	**VERIFY IF MALFUNCTION CAUSED BY CONFIGURATION ERROR** • Perform the SAS control module configuration using the M-MDS. (See SAS CONTROL MODULE CONFIGURATION (USING AS-BUILT DATA) [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs displayed?	Yes	Re-perform the configuration, then perform the DTC inspection. • If the same DTC is displayed, replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		No	DTC troubleshooting completed.