DTC B00D2:01 [TWO-STEP DEPLOYMENT CONTROL SYSTEM]

id0802b2824000

System malfunction location	• Air bag system warning light malfunction
Detection condition	**Warning** **• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.** • Air bag system warning light malfunction detected
Fail-safe function	Not applicable
Possible cause	• Air bag system warning light malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Action
Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)