DTC B00D5:55 [TWO-STEP DEPLOYMENT CONTROL SYSTEM]

id0802b2826900

System malfunction location	• Configuration setting error (indicator unit structural malfunction)
Detection condition	**Warning** **• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.** • PAD indicator illumination request sent from SAS control module does not correspond to PAD indicator illumination status in instrument cluster
Fail-safe function	Not applicable
Possible cause	• SAS control module configuration setting not implemented • SAS control module configuration setting invalid • Instrument cluster malfunction • Indicator unit assembly incorrect • Indicator unit malfunction • Indicator unit connector malfunction • SAS control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**PERFORM SAS CONTROL MODULE CONFIGURATION (AS-BUILT DATA USE)** • Perform the SAS control module configuration using the M-MDS. (See SAS CONTROL MODULE CONFIGURATION (USING AS-BUILT DATA) [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs present?	Yes	Go to the next step.
		No	DTC troubleshooting completed.
2	**PERFORM INSTRUMENT CLUSTER DTC INSPECTION** • Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs present?	Yes	Perform the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
3	**INSPECT INDICATOR UNIT CONNECTOR** • Switch the ignition off. • Disconnect the negative battery cable and wait for **1 min or more**. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.) • Disconnect the indicator unit connector. (See INDICATOR UNIT REMOVAL/ INSTALLATION.) • Inspect the indicator unit terminal for poor connection (such as damaged/pulled-out pins, and corrosion). • Is there any malfunction?	Yes	Replace the malfunctioning part, then go to next step.
		No	Go to the next step.

Step	Inspection		Action
4	**INSPECT INDICATOR UNIT** • Inspect the indicator unit. (See INDICATOR UNIT INSPECTION.) • Is there any malfunction?	Yes	Replace the indicator unit. (See INDICATOR UNIT REMOVAL/INSTALLATION.)
		No	Perform the inspection from Step 1. • If the malfunction recurs, replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)