SIDE AIR BAG SENSOR [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0810b2501300

Purpose
- The side air bag sensor detects an impact during a lateral collision.

Function
- The side air bag sensor converts the detected impact to an electrical signal.

Construction
- The side air bag sensor is built into the crash sensor.
- The side air bag sensor is located in the B-pillar in the lower part of the pillar.



am2zzn00002827

Operation
- For the side air bag sensor operation, refer to the AIR BAG SYSTEM. (See AIR BAG SYSTEM [STANDARD DEPLOYMENT CONTROL SYSTEM].)

Fail-safe
- Not applicable