
INSPECTION OF SST (DEPLOYMENT TOOL) [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0810b2801000

1. Before using the **SST (49 H066 002)**, inspect its operation.




am3zzw00011088

Inspection Procedure

1. Follow the steps below to inspect the **SST (49 H066 002)**.
   - If not as indicated in the table, replace the **SST (49 H066 002)** because it has a malfunction.

   Warning
   - **Do not use a malfunctioning SST (49 H066 002), otherwise it could cause the air bag module or pre-tensioner seat belt to accidentally operate (deploy).**

   Caution
   - **Because the permissible voltage for the SST (49 H066 002) is 12 V, do not connect a 24 V power source because it will damage the SST. Always connect only a 12 V power source.**



ac5uuw00002528

Step	Inspection procedure	Light condition	
		Green	Red
1	Connect the power supply red clip to the positive battery terminal, and the black clip to the negative battery terminal.	On	Off
2	Connect connectors A and B.	Off	On
3	Press the activation switch.	On	Off