DTC TABLE [BLIND SPOT MONITORING (BSM) SYSTEM]

id09021o064300

×: Applicable
—: Not applicable

DTC No.	Blind spot monitoring (BSM) OFF indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B11CB:11	On	Blind spot monitoring (BSM) warning light (RH) circuit malfunction	×	—	C, D	×	(See DTC B11CB:11 [BLIND SPOT MONITORING (BSM) SYSTEM].)
B11CB:15	On	Blind spot monitoring (BSM) warning light (RH) circuit malfunction	×	—	C, D	×	(See DTC B11CB:15 [BLIND SPOT MONITORING (BSM) SYSTEM].)
B11D3:11	On	Blind spot monitoring (BSM) warning light (LH) circuit malfunction	×	—	C, D	×	(See DTC B11D3:11 [BLIND SPOT MONITORING (BSM) SYSTEM].)
B11D3:15	On	Blind spot monitoring (BSM) warning light (LH) circuit malfunction	×	—	C, D	×	(See DTC B11D3:15 [BLIND SPOT MONITORING (BSM) SYSTEM].)
B11F2:23	On	Blind spot monitoring (BSM) switch circuit malfunction	×	—	C, D	×	(See DTC B11F2:23 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U0001:88	On	Unit communication error (MS-CAN)	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0121:00/ U0155:00/U0214:00 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U0028:87	On	Blind spot monitoring (BSM) control module (LH) and (RH) communication error	×	—	C, D	×	(See DTC U0028:87 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U0100:00	On	Communication error with PCM	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0121:00/ U0155:00/U0214:00 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U0121:00	On	Communication error with DSC HU/CM	×	—	C, D	×	
U0155:00	On	Communication error with instrument cluster	×	—	C, D	×	
U0214:00	On	Communication error with start stop unit	×	—	C, D	×	
U0401:68	On	Error signal received from PCM	×	—	C, D	×	(See DTC U0401:68 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U0415:68	On	Error signal received from DSC HU/CM	×	—	C, D	×	(See DTC U0415:68 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U0423:68	On	Error signal received from instrument cluster	×	—	C, D	×	(See DTC U0423:68 [BLIND SPOT MONITORING (BSM) SYSTEM].)

DTC No.	Blind spot monitoring (BSM) OFF indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U0515:68	On	Error signal received from start stop unit	×	—	C, D	×	(See DTC U0515:68 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U1A4B:16	On	Blind spot monitoring (BSM) control module (RH) low power supply voltage input	×	—	C, D	×	(See DTC U1A4B:16 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U1A4B:17	On	Blind spot monitoring (BSM) control module (RH) high power supply voltage input	×	—	C, D	×	(See DTC U1A4B:17 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U1A4B:43	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	(See DTC U1A4B:43/ U1A4B:44/U1A4B:45/ U1A4B:46/U1A4B:47/ U1A4B:48/U1A4B:49/ U1A4B:96 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U1A4B:44	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	
U1A4B:45	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	
U1A4B:46	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	
U1A4B:47	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	
U1A4B:48	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	
U1A4B:49	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	
U1A4B:54	On	Radar aiming is not performed or radar sensor axis is deviated (Blind spot monitoring (BSM) control module (RH))	×	—	C, D	×	(See DTC U1A4B:54 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U1A4B:96	On	Blind spot monitoring (BSM) control module (RH) malfunction	×	—	C, D	×	(See DTC U1A4B:43/ U1A4B:44/U1A4B:45/ U1A4B:46/U1A4B:47/ U1A4B:48/U1A4B:49/ U1A4B:96 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U1A4B:97	On	Radar sensor sensitivity temporarily decreases depending on various external and environmental factors (Blind spot monitoring (BSM) control module (RH))	×	—	C, D	×	(See DTC U1A4B:97 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U2300:54	On	Configuration data not received from instrument cluster	×	—	C, D	×	(See DTC U2300:54 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U2300:55	On	Instrument cluster configuration not implemented	×	—	C, D	×	(See DTC U2300:55 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U2300:56	On	Configuration data unmatched with instrument cluster	×	—	C, D	×	(See DTC U2300:56 [BLIND SPOT MONITORING (BSM) SYSTEM].)

DTC No.	Blind spot monitoring (BSM) OFF indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U2300:64	On	Instrument cluster configuration error (signal error) detected.	×	—	C, D	×	(See DTC U2300:64 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3000:42	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	(See DTC U3000:42/ U3000:43/U3000:44/ U3000:45/U3000:46/ U3000:47/U3000:48/ U3000:49/U3000:96 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3000:43	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:44	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:45	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:46	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:47	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:48	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:49	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	
U3000:4B	On	Temperature temporarily increases depending on various external and environmental factors (Blind spot monitoring (BSM) control module (LH) or (RH))	×	—	C, D	×	(See DTC U3000:4B [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3000:54	On	Radar aiming is not performed or radar sensor axis is deviated (Blind spot monitoring (BSM) control module (LH))	×	—	C, D	×	(See DTC U3000:54 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3000:96	On	Blind spot monitoring (BSM) control module (LH) malfunction	×	—	C, D	×	(See DTC U3000:42/ U3000:43/U3000:44/ U3000:45/U3000:46/ U3000:47/U3000:48/ U3000:49/U3000:96 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3000:97	On	Radar sensor sensitivity temporarily decreases depending on various external and environmental factors (Blind spot monitoring (BSM) control module (LH))	×	—	C, D	×	(See DTC U3000:97 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3003:16	On	Blind spot monitoring (BSM) control module (LH) low power supply voltage input	×	—	C, D	×	(See DTC U3003:16 [BLIND SPOT MONITORING (BSM) SYSTEM].)
U3003:17	On	Blind spot monitoring (BSM) control module (LH) high power supply voltage input	×	—	C, D	×	(See DTC U3003:17 [BLIND SPOT MONITORING (BSM) SYSTEM].)

*1 : C: CMDTC self test, D: ODDTC self test