PID/DATA MONITOR TABLE [BLIND SPOT MONITORING (BSM) SYSTEM]

id09021o560100

—: Not applicable

PID name	Unit/Status	Data contents	Module control terminal
Buzzer	Off/On	• Off: Blind spot monitoring (BSM) warning buzzer does not sound. • On: Blind spot monitoring (BSM) warning buzzer sounds.	D,E (CAN)
INTNL_TMP_L	°C, °F	Displays Blind spot monitoring (BSM) control module (LH) internal temperature.	—
INTNL_TMP_R	°C, °F	Displays Blind spot monitoring (BSM) control module (RH) internal temperature.	G, J (CAN)
MAIN_SW	Off/On	• Off: Blind spot monitoring (BSM) switch not pressed • On: Blind spot monitoring (BSM) switch pressed	A, D (CAN)
OP_BRT_L	—	Displays the Blind spot monitoring (BSM) warning light (LH) output brightness.	—
OP_BRT_R	—	Displays the Blind spot monitoring (BSM) warning light (RH) output brightness.	G, J (CAN)
SYSTEM_ST	Off/ Passive_On /Active_On/ Failure	• Off: Blind spot monitoring (BSM) system does not operate. • Passive_On: Blind spot monitoring (BSM) system is on standby. • Active_On: Blind spot monitoring (BSM) system operates. • Failure: Blind spot monitoring (BSM) system malfunction.	—
TURN_SW_L	Off/On	• Off: Turn switch is in position other than LH. • On: Turn switch is in LH position.	D, E (CAN)
TURN_SW_R	Off/On	• Off: Turn switch is in position other than RH. • On: Turn switch is in RH position.	D, E (CAN)
VPWR_L	V	Displays Blind spot monitoring (BSM) control module (LH) power supply voltage.	I
VPWR_R	V	Displays Blind spot monitoring (BSM) control module (RH) power supply voltage.	G, J (CAN)
VSPD	KPH, MPH	Displays the vehicle speed.	D, E (CAN)
WRN_IND_L	Off/On	• On: Blind spot monitoring (BSM) warning indicator light (LH) turns off. • Off: Blind spot monitoring (BSM) warning indicator light (LH) turns on.	G, J (CAN)
WRN_IND_R	Off/On	• On: Blind spot monitoring (BSM) warning indicator light (RH) turns off. • Off: Blind spot monitoring (BSM) warning indicator light (RH) turns on.	G, J (CAN)
YAW_RATE	°/s	• —: Vehicle is stopped or while moving straight ahead. • Exceeds 0°/s: Vehicle tilted left. • Less than 0°/s: Vehicle tilted right.	D, E (CAN)