ACTIVE COMMAND MODES TABLE [BLIND SPOT MONITORING (BSM) SYSTEM]

id09021o560300

Note
- Simulation items on parts which are not equipped to the vehicle do not operate.

Simulation item	Unit/ Operation	Data contents	Output part name	Operation condition
Buzzer	Off/On	• Off: Blind spot monitoring (BSM) warning buzzer does not sound. • On: Blind spot monitoring (BSM) warning buzzer sounds.	Blind spot monitoring (BSM) warning buzzer (instrument cluster)	Ignition switched ON (engine off or on)
WRN_IND_L	Off/On	• Off: Turns off the blind spot monitoring (BSM) warning light (LH). • On: Illuminates the blind spot monitoring (BSM) warning light (LH).	Blind spot monitoring (BSM) warning light (LH)	Ignition switched ON (engine off or on)
WRN_IND_R	Off/On	• Off: Turns off the blind spot monitoring (BSM) warning light (RH). • On: Illuminates the blind spot monitoring (BSM) warning light (RH).	Blind spot monitoring (BSM) warning light (RH)	Ignition switched ON (engine off or on)