SECURITY INDICATOR LIGHT: 13, DTC: B13D3:05/P1260:00 [IMMOBILIZER SYSTEM]

id0902e4027900

Description	Remote transmitter program error
Detection condition	• Start stop unit detects a remote transmitter program error.
Fail-safe	Not applicable
Possible cause	• Push button start connector or terminal malfunction • Start stop unit connector or terminal malfunction • Remote transmitter program error • Start stop unit malfunction **Note** • If any of the following items are touching or near the remote transmitter, signal communication between the remote transmitter and the vehicle is negatively affected, resulting in the engine not starting. — Spare keys — Keys for other vehicles equipped with an immobilizer system — Any metallic object — Any electronic device, or any credit or other card with magnetic strips — Radio wave outputting device nearby
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**INSPECT PUSH BUTTON START CONNECTOR CONDITION** • Switch the ignition off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.) • Disconnect the push button start connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal?	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 4.
2	**INSPECT START STOP UNIT CONNECTOR CONDITION** • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal?	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 4.

Step	Inspection		Action
3	**VERIFY IF MALFUNCTIONING LOCATION IS REMOTE TRANSMITTER DEPENDING ON REPEATABILITY** • Always reconnect all disconnected connectors. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.) • Clear the DTC for the immobilizer system using the M-MDS. (See CLEARING DTC [IMMOBILIZER SYSTEM].) • Re-program key ID number of the remote transmitter. (See IMMOBILIZER SYSTEM-RELATED PARTS PROGRAMMING.) • Retrieve the immobilizer system DTCs using the M-MDS. (See DTC INSPECTION [IMMOBILIZER SYSTEM].) • Is the security indicator light: 13, DTC B13D3:05/P1260:00 displayed?	Yes	Replace the remote transmitter, then go to the next step. (See IMMOBILIZER SYSTEM-RELATED PARTS PROGRAMMING.)
		No	Go to Step 5.
4	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Always reconnect all disconnected connectors. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.) • Clear the DTC for the immobilizer system using the M-MDS. (See CLEARING DTC [IMMOBILIZER SYSTEM].) • Re-program key ID number of the remote transmitter. (See IMMOBILIZER SYSTEM-RELATED PARTS PROGRAMMING.) • Retrieve the immobilizer system DTCs using the M-MDS. (See DTC INSPECTION [IMMOBILIZER SYSTEM].) • Is the security indicator light: 13, DTC B13D3:05/P1260:00 displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
5	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [IMMOBILIZER SYSTEM].)
		No	DTC troubleshooting completed.