
DTC TABLE [IMMOBILIZER SYSTEM]

id0902e4028700

×: Applicable
—: Not applicable

DTC				KEY warning light (red)	Push button start indicator light (amber)	Description	Fail-safe	Drive cycle	Self test type *2	Memory function	Page
M-MDS display*1		Security indicator light flash pattern									
Start stop unit	PCM										
U3000:96	P1260:00	09		On	Flash	Start stop unit malfunction	—	—	C	×	(See SECURITY INDICATOR LIGHT: 09, DTC: U3000:96/ P1260:00 [IMMOBILIZER SYSTEM].)
B10D9:87	P1260:00	11		—	Flash	Coil antenna (built into push button start) error	—	—	C	—	(See SECURITY INDICATOR LIGHT: 11, DTC: B10D9:87/ P1260:00 [IMMOBILIZER SYSTEM].)
B13D3:05	P1260:00	13		—	—	Remote transmitter program error	—	—	C	—	(See SECURITY INDICATOR LIGHT: 13, DTC: B13D3:05/ P1260:00 [IMMOBILIZER SYSTEM].)
B13D3:94	P1260:00	13		—	—	Communication error with remote transmitter	—	—	C	—	(See SECURITY INDICATOR LIGHT: 13, DTC: B13D3:94/ P1260:00 [IMMOBILIZER SYSTEM].)
B13D3:51	P1260:00	15		—	Flash	Unregistered remote transmitter is detected	—	—	C	—	(See SECURITY INDICATOR LIGHT: 15, DTC: B13D3:51/ P1260:00 [IMMOBILIZER SYSTEM].)
U0100:87	P1260:00	16		—	—	Communication error with PCM (no response or data mis-match)	—	—	C	—	(See SECURITY INDICATOR LIGHT: 16, DTC: U0100:87/ P1260:00 [IMMOBILIZER SYSTEM].)

DTC				KEY warning light (red)	Push button start indicator light (amber)	Description	Fail-safe	Drive cycle	Self test type *2	Memory function	Page
M-MDS display*1		Security indicator light flash pattern									
Start stop unit	PCM										
B13D4:00	P1260:00	21		On	—	Insufficient remote transmitter programming number	—	—	C	—	(See SECURITY INDICATOR LIGHT: 21, DTC: B13D4:00/ P1260:00 [IMMOBILIZER SYSTEM].)
B10DA:51	P1260:00	22		—	—	Communication error with PCM (data received failure)	—	—	C	—	(See SECURITY INDICATOR LIGHT: 22, DTC: B10DA:51/ P1260:00 [IMMOBILIZER SYSTEM].)
B10DA:62	P1260:00	23		—	—	Communication error with PCM (code mis-matched)	—	—	C	—	(See SECURITY INDICATOR LIGHT: 23, DTC: B10DA:62/ P1260:00 [IMMOBILIZER SYSTEM].)

*1 : The letters at the beginning of each DTC are only displayed when using the M-MDS, and refer to the following: B= Body system, P= Powertrain system, U= Network communication system.

*2 : C: CMDTC self test, D: ODDTC self test