PID/DATA MONITOR TABLE [IMMOBILIZER SYSTEM]

id0902e4028900

—: Not applicable

PID	Unit/ Operation	Data contents	Data read/use method	Module control terminal
NUM_TRNSMIT	—	Displays number of the remote transmitters programmed to the start stop unit	—	—