DTC C1132:41 [INSTRUMENT CLUSTER]

id0902e8605700

Description	Malfunction inside instrument cluster
Detection condition	• The instrument cluster detects that there is an active driving display malfunction in the instrument cluster.
Fail-safe	Not applicable
Possible cause	• Active driving display malfunction • Instrument cluster malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**INSPECT ACTIVE DRIVING DISPLAY** • Inspect the active driving display. (See ACTIVE DRIVING DISPLAY INSPECTION.) • Is the active driving display normal?	Yes	Go to the next step.
		No	Replace the active driving display, then go to the next step. (See ACTIVE DRIVING DISPLAY REMOVAL/ INSTALLATION.)
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].) • Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.) Go to the next step.
		No	Go to the next step.
3	**VERIFY OTHER DTCs** • Are any other DTCs displayed?	Yes	Repair the malfunctioning location according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	DTC troubleshooting completed.