DTC U0422:68 [INSTRUMENT CLUSTER]

id0902e8950800

Description	Error signal received from BCM
Detection condition	• Instrument cluster receives the error signals from the BCM for **5 s or more** with the ignition switched ON (engine off or on).
Fail-safe	Not applicable
Possible cause	• DTCs are stored in the BCM. • BCM malfunction • Instrument cluster malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs** • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	Go to the next step.
2	**VERIFY IF MALFUNCTIONING LOCATION IS BCM DEPENDING ON REPEATABILITY** • Clear the DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].) • Switch the ignition ON (engine off or on) and wait for **20 s or more**. • Retrieve the instrument cluster DTCs using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to Step 4.
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].) • Switch the ignition ON (engine off or on) and wait for **20 s or more**. • Retrieve the instrument cluster DTCs using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the same DTC displayed?	Yes	Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	DTC troubleshooting completed.