DTC TABLE [INSTRUMENT CLUSTER]

id0902e8960500

×: Applicable
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B1B71:14 *2	—	Evaporator temperature sensor circuit malfunction	—	—	C, D	×	(See DTC B1B71:14 [INSTRUMENT CLUSTER].)
C1132:41 *3	—	Malfunction inside instrument cluster	—	—	C, D	×	(See DTC C1132:41 [INSTRUMENT CLUSTER].)
U0001:88	—	Module communication error (HS-CAN)	—	—	C, D	×	(See DTC U0001:88/ U0010:88/U0100:00/ U0101:00/U0121:00/ U0131:00/U0140:00/ U0151:00/U0156:00/ U0164:00/U0182:00/ U0214:00/U0232:00/ U0235:00/U023A:00 [INSTRUMENT CLUSTER].)
U0010:88	—	Module communication error (MS-CAN)	—	—	C, D	×	
U0100:00	Illuminated /Flash	Communication error with PCM	—	—	C, D	×	
U0101:00 *4	—	Communication error with TCM	—	—	C, D	×	
U0121:00	Illuminated /Flash	Communication error with ABS HU/CM or DSC HU/CM	—	—	C, D	×	
U0131:00	Illuminated /Flash	Communication error with EPS control module	—	—	C, D	×	
U0140:00	Illuminated /Flash	Communication error with BCM	—	—	C, D	×	
U0151:00	Illuminated /Flash	Communication error with SAS control module	—	—	C, D	×	
U0156:00 *5	Illuminated /Flash	Communication error with connectivity master unit (CMU)	—	—	C, D	×	
U0164:00 *6	—	Communication error with climate control unit	—	—	C, D	×	
U0182:00 *7	Illuminated /Flash	Communication error with auto leveling control module	—	—	C, D	×	
U0214:00	Illuminated /Flash	Communication error with start stop unit	—	—	C, D	×	
U0232:00 *8	Illuminated /Flash	Communication error with blind spot monitoring (BSM) control module (LH)	—	—	C, D	×	
U0235:00 *9	—	Communication error with laser sensor	×	—	C, D	×	
U023A:00*10	Illuminated /Flash	Communication error with forward sensing camera (FSC)	—	—	C, D	×	
U0300:00 *3	—	Instrument cluster configuration error	—	—	C, D	×	(See DTC U0300:00 [INSTRUMENT CLUSTER].)
U0401:68	Illuminated /Flash	Error signal received from PCM	—	—	C, D	×	(See DTC U0401:68 [INSTRUMENT CLUSTER].)
U0402:68 *4	—	Error signal received from transmission/transaxle	—	—	C, D	×	(See DTC U0402:68 [INSTRUMENT CLUSTER].)
U0422:68	Illuminated /Flash	Error signal received from BCM	—	—	C, D	×	(See DTC U0422:68 [INSTRUMENT CLUSTER].)
U0433:00 *9	—	Error signal received from laser sensor	×	—	C, D	×	(See DTC U0433:00 [INSTRUMENT CLUSTER].)
U0515:68	Illuminated /Flash	Error signal received from start stop unit	—	—	C, D	×	(See DTC U0515:68 [INSTRUMENT CLUSTER].)

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U053B:00*10	Illuminated /Flash	Error signal received from forward sensing camera (FSC)	—	—	C, D	×	(See DTC U053B:00 [INSTRUMENT CLUSTER].)
U2005:86	—	Error signal received from PCM	—	—	C, D	×	(See DTC U2005:86 [INSTRUMENT CLUSTER].)
U2013:13	—	Cluster switch circuit malfunction	—	—	C, D	×	(See DTC U2013:13 [INSTRUMENT CLUSTER].)
U2100:00	—	Instrument cluster configuration error	—	—	C, D	×	(See DTC U2100:00 [INSTRUMENT CLUSTER].)
U2105:02 *11	—	Drive selection switch circuit malfunction	—	—	C, D	×	(See DTC U2105:02 [INSTRUMENT CLUSTER].)
U2300:41	—	Instrument cluster configuration error	—	—	C, D	×	(See DTC U2300:41 [INSTRUMENT CLUSTER].)
U2300:51	—	Instrument cluster configuration error	—	—	C, D	×	(See DTC U2300:51 [INSTRUMENT CLUSTER].)
U2300:56	—	Instrument cluster configuration error	—	—	C, D	×	(See DTC U2300:56 [INSTRUMENT CLUSTER].)
U2300:57	—	Instrument cluster configuration error	—	—	C, D	×	(See DTC U2300:57 [INSTRUMENT CLUSTER].)
U3000:41 *3	—	Instrument cluster internal malfunction	—	—	C, D	×	(See DTC U3000:41 [INSTRUMENT CLUSTER].)
U3003:16	—	Low power supply voltage input to instrument cluster	—	—	C, D	×	(See DTC U3003:16 [INSTRUMENT CLUSTER].)

*1 : C: CMDTC self test, D: ODDTC self test
*2 : With manual air conditioner system
*3 : With digital speedometer
*4 : ATX
*5 : With center display
*6 : With digital speedometer and full-auto air conditioner system
*7 : With headlight auto leveling system
*8 : With blind spot monitoring (BSM) system
*9 : With smart city brake support (SCBS)
*10 : With forward sensing camera (FSC)
*11 : With drive selection switch