PID/DATA MONITOR TABLE [INSTRUMENT CLUSTER]

id0902e8960700

—: Not applicable

PID	Unit/ Operation	Data contents	Module control terminal
AFS_ST	Off/On	Displays in the M-MDS but it does not operate.	
AT_MAN_M_SW*1	Off/On/ Reserved/ Unknown	• Off: M position switch is off. • On: M position switch is on. • Reserved: — • Unknown: M position switch signal is not determined.	1H
AT_S_DWN_SW*1	Off/On/ Reserved/ Unknown	• Off: Down switch is off. • On: Down switch is on. • Reserved: — • Unknown: Down switch signal is not determined.	1G
AT_S_UP_SW*1	Off/On/ Reserved/ Unknown	• Off: Up switch is off. • On: Up switch is on. • Reserved: — • Unknown: Up switch signal is not determined.	1F
BSM/RVM_SW*2	Off/On	• Off: Blind spot monitoring (BSM) OFF switch is off. • On: Blind spot monitoring (BSM) OFF switch is on.	1A, 1V
DSC_OFF_SW	Off/On	• Off: DSC OFF switch is off. • On: DSC OFF switch is on.	1A, 1V
FUEL_GAUGE	L	Displays fuel level detected by the fuel gauge	—
FUEL_SEN_M	ohm	Displays fuel gauge sender unit resistance valve.	—
	V	Displays in the M-MDS but it does not operate.	
FUEL_SEN_S	ohm	Displays in the M-MDS but it does not operate.	
	V	Displays in the M-MDS but it does not operate.	
I_ILLUMI_M	Off (Day)/On (Night)	• Off (Day): TNS switch is off. • On (Night): TNS switch is on.	1B, 1D
I-ST_OFF_SW	Off/On	• Off: i-stop OFF switch is off. • On: i-stop OFF switch is on.	1A, 1V
LDWS_ON_SW *3	Off/On	• Off: LDWS switch is off. • On: LDWS switch is on.	1A, 1V
MULTI_SW_ST	O.K./FAULT	• O.K.: Cluster switch is normal. • FAULT: Cluster switch is malfunctioning.	1A, 1V
ODO_CNT	km, ft, mi	Displays rolling count of the odometer	—
P_BRAKE_SW	Off/On	• Off: Parking brake not applied • On: Parking brake applied	1X
R_GEAR_SW	Off/On	**ATX** • Off: Selector lever is in other than R position. • On: Selector lever is in R position. **MTX** • Off: Back-up light switch is off. • On: Back-up light switch is on.	1B, 1D
R_LMP	Off/On/ Unknown/ Fault	• Off: Back-up light is turned off. • On: Back-up light is turned on. • Unknown: Back-up light signal is not determined. • Fault: Back-up light malfunction	1B, 1D
SPEEDOMTR	KPH, MPH	Displays vehicle speed	—
TACHOMTR	RPM	Displays engine speed	—
TOTAL_TIME	hh:mm:ss	Displays cumulative elapsed time since vehicle completion	—
TPMS_CAL_SW*4	Off/On	• Off: Tire pressure monitoring system (TPMS) set switch is off. • On: Tire pressure monitoring system (TPMS) set switch is on.	1A, 1V
VPWR	V	Displays power supply voltage	1S, 1U

*1 : ATX

*2 : With blind spot monitoring (BSM) system

*3 : With lane departure warning system (LDWS)

*4 : With tire pressure monitoring system (TPMS)