ACTIVE COMMAND MODES TABLE [INSTRUMENT CLUSTER]

id0902e8960900

Note
- Simulation items on parts which are not equipped to the vehicle do not operate.

Simulation item	Unit/ Operation	Data contents	Output part name	Operation condition
ALARM	On/Off	• On: Warning alarm sounds. • Off: Warning alarm does not sound.	Warning alarm (instrument cluster)	Ignition switched ON (engine off or on)
LCD_SEG	Off/On	• Off: Turns off the LCD. • On: Fully displays LCD.	LCD (instrument cluster)	Ignition switched ON (engine off or on)
SPEEDOMTR*1	Off/60 Km/h/ 120 Km/h	• Off: Speedometer needle moves to the bottommost position. • 60 Km/h: Speedometer needle moves to **approx. 61—67 km/h {38—42 mph}**. • 120 Km/h: Speedometer needle moves to **approx. 122—130 km/h {75—81 mph}**.	Speedometer (instrument cluster)	Ignition switched ON (engine off or on)
TACHOMTR*2	Off/3000 RPM/6000 RPM	• Off: Tachometer needle moves to bottommost position. • 3000 RPM: Tachometer needle moves to **approx. 3,050 rpm**. • 6000 RPM: Tachometer needle moves to **approx. 6,100 rpm**.	Tachometer (instrument cluster)	Ignition switched ON (engine off or on)
WL+IL	Off/On	• Off: Turns off all warning lights, indicator lights. • On: Illuminates all warning lights, indicator lights.	Warning lights, indicator lights (instrument cluster)	Ignition switched ON (engine off or on)

*1 : Analog speedometer type
*2 : Analog tachometer type