## DTC U3000:41 [INSTRUMENT CLUSTER]

id0902e8999500

| Description | Instrument cluster internal malfunction |
|---|---|
| Detection condition | • Instrument cluster detects the internal malfunction. |
| Fail-safe | Not applicable |
| Possible cause | • Instrument cluster malfunction |
| System wiring diagram | Not applicable |

### Diagnostic Procedure

| Step | Inspection | | Action |
|---|---|---|---|
| 1 | **VERIFY IF MALFUNCTIONING LOCATION IS INSTRUMENT CLUSTER DEPENDING ON REPEATABILITY**<br>• Clear the DTC for the instrument cluster using the M-MDS.<br>(See CLEARING DTC [INSTRUMENT CLUSTER].)<br>• Retrieve the instrument cluster DTCs using the M-MDS.<br>(See DTC INSPECTION [INSTRUMENT CLUSTER].)<br>• Is the same DTC displayed? | Yes | Replace the instrument cluster, then go to the next step.<br>(See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.) |
| | | No | Go to the next step. |
| 2 | **VERIFY IF OTHER DTCs DISPLAYED**<br>• Are any other DTCs displayed? | Yes | Repair or replace the malfunctioning part according to the applicable DTC troubleshooting.<br>(See DTC TABLE [INSTRUMENT CLUSTER].) |
| | | No | DTC troubleshooting completed. |