DTC TABLE [BCM]

id0902f5067500

×: Applicable
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B1048:7B	—	Brake fluid level sensor circuit malfunction	—	—	D	×	(See DTC B1048:7B [BCM].)
B1079:13*2	—	Bonnet latch switch circuit malfunction	—	—	D	×	(See DTC B1079:13 [BCM].)
B108F:16*3	—	Door lock switch circuit malfunction	—	—	D	×	(See DTC B108F:16 [BCM].)
B109E:87	—	Communication error with start stop unit	—	—	C, D	×	(See DTC B109E:87 [BCM].)
B109F:49*4	—	Intruder sensor internal malfunction	—	—	C, D	×	(See DTC B109F:49 [BCM].)
B109F:87*4	—	Communication error with intruder sensor	—	—	C, D	×	(See DTC B109F:87 [BCM].)
B10A0:64	—	Wiper and washer switch error signal received	×	—	C, D	×	(See DTC B10A0:64 [BCM].)
B10A5:49*4	—	Theft-deterrent siren internal malfunction	—	—	C, D	×	(See DTC B10A5:49 [BCM].)
B10A5:87*4	—	Communication error with theft-deterrent siren	—	—	C, D	×	(See DTC B10A5:87 [BCM].)
B10A6:62	—	Light switch position signal error	×	—	C, D	×	(See DTC B10A6:62 [BCM].)
B10A6:64	—	Light switch error signal received	×	—	C, D	×	(See DTC B10A6:64 [BCM].)
B10AD:49*5	—	Auto light sensor/rain sensor internal malfunction	×	—	C, D	×	(See DTC B10AD:49 [BCM].)
B10AD:56*5	—	Auto light sensitivity mismatch	×	—	C, D	×	(See DTC B10AD:56 [BCM].)
B10AD:86*5	—	Auto wiper control request signal error	×	—	C, D	×	(See DTC B10AD:86 [BCM].)
B113E:11	—	**4SD** • Trunk lid opener switch (exterior) circuit malfunction **5HB** • Liftgate opener switch circuit malfunction	—	—	D	×	(See DTC B113E:11 [BCM].)
B1172:11	—	Front door lock-link switch (driver's side) unlock circuit malfunction	—	—	D	×	(See DTC B1172:11 [BCM].)
B1172:13	—	Front door lock-link switch (driver's side) unlock circuit malfunction	—	—	D	×	(See DTC B1172:13 [BCM].)
B1174:11*6	—	Door lock-link switch unlock circuit malfunction	—	—	D	×	(See DTC B1174:11 [BCM].)
B1174:13*6	—	Door lock-link switch unlock circuit malfunction	—	—	D	×	(See DTC B1174:13 [BCM].)
B1175:11	—	Front door latch switch (driver's side) circuit malfunction	—	—	D	×	(See DTC B1175:11 [BCM].)
B1176:11	—	Front door latch switch (passenger's side) circuit malfunction	—	—	D	×	(See DTC B1176:11 [BCM].)

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B1178:11	—	**4SD** • Trunk lid latch switch circuit malfunction **5HB** • Liftgate latch switch circuit malfunction	—	—	D	×	(See DTC B1178:11 [BCM].)
B11DA:16	—	Front door key cylinder switch (driver's side) circuit malfunction	—	—	D	×	(See DTC B11DA:16 [BCM].)
B11DB:86	—	Error signal received from current sensor	—	—	C, D	×	(See DTC B11DB:86 [BCM].)
B11E9:11	—	Rear door latch switch (LH) circuit malfunction	—	—	D	×	(See DTC B11E9:11 [BCM].)
B11EA:11	—	Rear door latch switch (RH) circuit malfunction	—	—	D	×	(See DTC B11EA:11 [BCM].)
B1219:11*7	—	Trunk lid opener switch (interior) circuit malfunction	—	—	D	×	(See DTC B1219:11 [BCM].)
B126A:11	—	Front door lock-link switch (driver's side) lock circuit malfunction	—	—	D	×	(See DTC B126A:11 [BCM].)
B126A:13	—	Front door lock-link switch (driver's side) lock circuit malfunction	—	—	D	×	(See DTC B126A:13 [BCM].)
B12D3:11	—	Front door lock-link switch (driver's side) circuit malfunction	—	—	C, D	×	(See DTC B12D3:11 [BCM].)
B1D06:11	—	Turn light (LH) circuit malfunction	—	—	C, D	×	(See DTC B1D06:11 [BCM].)
B1D06:13	—	Turn light (LH) circuit malfunction	—	—	C, D	×	(See DTC B1D06:13 [BCM].)
B1D07:11	—	Turn light (RH) circuit malfunction	—	—	C, D	×	(See DTC B1D07:11 [BCM].)
B1D07:13	—	Turn light (RH) circuit malfunction	—	—	C, D	×	(See DTC B1D07:13 [BCM].)
B1D35:86	—	Hazard warning switch error signal received	×	—	C, D	×	(See DTC B1D35:86 [BCM].)
B1D36:86	—	Turn switch error signal received	×	—	C, D	×	(See DTC B1D36:86 [BCM].)
C0023:14 *8	—	Brake light circuit malfunction	×	—	C, D	×	(See DTC C0023:14 [BCM].)
C1137:86	—	Back-up light on request error signal received	×	—	C, D	×	(See DTC C1137:86 [BCM].)
U0001:88	—	Module communication error (HS-CAN)	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0151:00/ U0155:00/U0214:00/ U023A:00 [BCM].)
U0100:00	—	Communication error with PCM	×	—	C, D	×	
U0101:00 *9	—	Communication error with TCM	—	—	C, D	×	
U0121:00	—	Communication error with ABS HU/CM or DSC HU/CM	—	—	C, D	×	
U0142:68	—	Communication error with electrical supply unit (ESU)	—	—	C, D	×	(See DTC U0142:68 [BCM].)
U0151:00	—	Communication error with SAS control module	—	—	C, D	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0151:00/ U0155:00/U0214:00/ U023A:00 [BCM].)
U0155:00	—	Communication error with instrument cluster	×	—	C, D	×	
U0214:00	—	Communication error with start stop unit	×	—	C, D	×	
U0231:68 *5	—	Communication error with auto light sensor/rain sensor	×	—	C, D	×	(See DTC U0231:68 [BCM].)

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U023A:00*10	—	Communication error with forward sensing camera (FSC)	—	—	C, D	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0151:00/ U0155:00/U0214:00/ U023A:00 [BCM].)
U0298:68 *11	—	Communication error with DC-DC converter	—	—	C, D	×	(See DTC U0298:68 [BCM].)
U0452:68	—	Fuel-cut error signal at time of collision received	—	—	C, D	×	(See DTC U0452:68 [BCM].)
U0515:41	—	Error signal received from start stop unit	×	—	C, D	×	(See DTC U0515:41 [BCM].)
U053B:68*10	—	Error signal received from forward sensing camera (FSC)	×	—	C, D	×	(See DTC U053B:68 [BCM].)
U0599:86 *11	—	Error signal received from DC-DC converter	—	—	C, D	×	(See DTC U0599:86 [BCM].)
U1007:68	—	Communication error with current sensor	—	—	C, D	×	(See DTC U1007:68 [BCM].)
U2300:54	—	Configuration data not received from instrument cluster	—	—	C, D	×	(See DTC U2300:54 [BCM].)
U2300:55	—	Instrument cluster configuration not implemented	—	—	C, D	×	(See DTC U2300:55 [BCM].)
U2300:56	—	Configuration data unmatched with instrument cluster	—	—	C, D	×	(See DTC U2300:56 [BCM].)
U3000:44	—	BCM internal malfunction	×	—	C, D	×	(See DTC U3000:44 [BCM].)
U3000:49	—	BCM internal malfunction	×	—	C, D	×	(See DTC U3000:49 [BCM].)
U3003:16	—	BCM power supply voltage low input	—	—	C, D	×	(See DTC U3003:16 [BCM].)
U3003:17	—	BCM power supply voltage high input	—	—	C, D	×	(See DTC U3003:17 [BCM].)

*1 : C: CMDTC self test, D: ODDTC self test
*2 : With bonnet latch switch
*3 : With door lock switch
*4 : With intruder sensor
*5 : With auto light/auto wiper system
*6 : With theft-deterrent system
*7 : With trunk lid opener switch (interior)
*8 : With smart city brake support (SCBS)
*9 : ATX
*10 : With forward sensing camera (FSC)
*11 : With i-stop, without i-ELOOP