DTC B10A0:64 [BCM]

id0902f5067700

Description	Wiper and washer switch error signal received
Detection condition	• BCM receives error signals from the start stop unit for **5 s or more** with the ignition switched ON (engine off or on).
Fail-safe	**Windshield wiper system** • Continue the controls prior to the windshield wiper malfunction detection. **Front washer system** • Stop the front washer control.
Possible cause	• Start stop unit malfunction • Wiper and washer switch malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 6.
2	**DETERMINE MALFUNCTIONING LOCATION BY PERFORMING PID/DATA MONITOR INSPECTION** • Using the M-MDS, display the following PIDs for the start stop unit. (See PID/DATA MONITOR INSPECTION [START STOP UNIT].) — WASHER_F — WASHER_R — WIP_F_INT — WIP_F_LOW — WIP_R_INT — WIP_R_ON • Does the PID monitoring value switch correctly according to the wiper and washer switch operation?	Yes	Go to Step 4. (circuit between wiper and washer switch and start stop unit is normal)
		No	Go to the next step.
3	**INSPECT WIPER AND WASHER SWITCH** • Inspect the wiper and washer switch. (See WIPER AND WASHER SWITCH INSPECTION.) • Is the wiper and washer switch normal?	Yes	Replace the start stop unit, then go to Step 5. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Replace the wiper and washer switch, then go to Step 5. (See WIPER AND WASHER SWITCH REMOVAL/INSTALLATION.)
4	**DETERMINE MALFUNCTIONING LOCATION BY PERFORMING PID/DATA MONITOR INSPECTION** • Using the M-MDS, display the following PIDs for the BCM. (See PID/DATA MONITOR INSPECTION [BCM]) — WIP_F_SW — WIP_R_SW • Does the PID monitoring value switch correctly according to the wiper and washer switch operation?	Yes	Go to the next step. (Circuit between start stop unit and BCM is normal.)
		No	Replace the start stop unit, then go to the next Step. (See START STOP UNIT REMOVAL/INSTALLATION.)

Step	Inspection		Action
5	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the BCM. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.) Go to the next step.
		No	Go to the next step.
6	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.