DTC B10A5:49 [BCM]

id0902f5067800

Description	Theft-deterrent siren internal malfunction
Detection condition	• BCM detects the theft-deterrent siren internal malfunction for **1.5 s or more**.
Fail-safe	Not applicable
Possible cause	• Theft-deterrent siren malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine on) and wait for **3 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 4.
2	**INSPECT THEFT-DETERRENT SIREN** • Inspect the theft-deterrent siren. (See THEFT-DETERRENT SIREN INSPECTION.) • Is the theft-deterrent siren normal?	Yes	Go to the next step.
		No	Replace the theft-deterrent siren, then go to the next step. (See THEFT-DETERRENT SIREN REMOVAL/ INSTALLATION.)
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine on) and wait for **3 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.