DTC B10AD:56 [BCM]

id0902f5068300

Description	Auto light sensitivity mismatch
Detection condition	• The BCM received the following mismatches for **5 s or more** with the ignition switched ON (engine off or on). — Auto light sensitivity setting required by BCM to set auto light sensor/rain sensor — Current value of auto light sensitivity setting which auto light sensor/rain sensor sends to BCM
Fail-safe	**Auto light system** • Continue the controls prior to the auto light malfunction detection.
Possible cause	• Auto light sensor/rain sensor malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS AUTO LIGHT SENSOR/RAIN SENSOR DEPENDING ON REPEATABILITY** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the auto light sensor/rain sensor, then go to the next step. (See RAIN SENSOR REMOVAL/INSTALLATION.)
		No	Go to Step 3.
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.