DTC U0452:68 [BCM]

id0902f5071300

Description	Fuel-cut error signal at time of collision received
Detection condition	• The BCM received a fuel-cut error signal at the time of a collision from the SAS control module for **3 s or more** with the ignition switched ON (engine off or on).
Fail-safe	Not applicable
Possible cause	• SAS control module malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **3 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 5.
2	**VERIFY SAS CONTROL MODULE DTCs** • Retrieve the SAS control module DTCs using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		No	Go to the next step.
3	**VERIFY IF MALFUNCTIONING LOCATION IS SAS CONTROL MODULE DEPENDING ON REPEATABILITY** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **3 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the SAS control module, then go to the next step. (See SAS CONTROL MODULE REMOVAL/ INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See SAS CONTROL MODULE REMOVAL/ INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
		No	Go to Step 5.
4	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **3 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the BCM. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.) Go to the next step.
		No	Go to the next step.
5	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.