DTC U0515:41 [BCM]

id0902f5071400

Description	Error signal received from start stop unit
Detection condition	• Check sum error occurred on communication with the BCM and the start stop unit **3 times continuously** with the ignition switched ON (engine off or on).
Fail-safe	**Exterior lighting system** • Turn the TNS and headlights LO on, and turn off other exterior light controls. **Auto light system** • Continue the controls prior to the auto light malfunction detection. **Windshield wiper system** • Continue the controls prior to the windshield wiper malfunction detection. **Front washer system** • Stop the front washer control. **Auto wiper system** • Continue the controls prior to the windshield wiper malfunction detection.
Possible cause	• Start stop unit malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 5.
2	**VERIFY START STOP UNIT DTCs** • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	Go to the next step.
3	**VERIFY IF MALFUNCTIONING LOCATION IS START STOP UNIT DEPENDING ON REPEATABILITY** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to Step 5.
4	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the BCM. (See BODY CONTROL MODULE (BCM) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
5	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.