DTC U053B:68 [BCM]

id0902f5071500

Description	Error signal received from forward sensing camera (FSC)
Detection condition	• BCM receives the error signals from the forward sensing camera (FSC) for **5 s or more** with the ignition switched ON (engine off or on).
Fail-safe	• Stop the headlight control done by the high beam control (HBC) system.
Possible cause	• Forward sensing camera (FSC) malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 5.
2	**VERIFY FORWARD SENSING CAMERA (FSC) DTCs** • Retrieve the forward sensing camera (FSC) DTCs using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)].)
		No	Go to the next step.
3	**VERIFY IF MALFUNCTIONING LOCATION IS FORWARD SENSING CAMERA (FSC) DEPENDING ON REPEATABILITY** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the forward sensing camera (FSC), then go to the next step. (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.)
		No	Go to Step 5.
4	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **5 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the BCM. (See BODY CONTROL MODULE (BCM) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
5	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.