DTC U2300:55 [BCM]

id0902f5071900

Description	Instrument cluster configuration not implemented
Detection condition	• The BCM does not perform the configuration with the ignition switched ON (engine off or on).
Fail-safe	Not applicable
Possible cause	**Note** • To correctly write the configuration data sent from the instrument cluster to the BCM to the BCM, **30 s or more** need to have elapsed since the ignition was switched ON (engine off or on). • Instrument cluster configuration is not completed. • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **30 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 4.
2	**RESET CONFIGURATION DATA FROM INSTRUMENT CLUSTER TO BCM** • Using the M-MDS, perform the instrument cluster configuration (using As-Built data). (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **30 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Using the M-MDS, perform the instrument cluster configuration (using As-Built data) again, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)
		No	Go to Step 4.
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **30 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.