DTC U3000:44 [BCM]

id0902f5072100

Description	BCM internal malfunction
Detection condition	• BCM detects the internal malfunction with the ignition switched ON (engine off or on).
Fail-safe	**Exterior lighting system** • Turn the TNS and headlights LO on, and turn off other exterior light controls. **Auto light system** • Continue the controls prior to the auto light malfunction detection. **Windshield wiper system** • Continue the controls prior to the windshield wiper malfunction detection. **Auto wiper system** • Continue the controls prior to the windshield wiper malfunction detection.
Possible cause	**Note** • If the negative battery cable is disconnected, this DTC may be output. • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS BCM DEPENDING ON REPEATABILITY** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.
2	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.