DTC U3003:17 [BCM]

id0902f5072400

Without i-ELOOP

Description	BCM power supply voltage high input
Detection condition	• The BCM detected the BCM power supply circuit (terminals 1A or 1B) voltage of **16 V or more** for **10 s or more** with the ignition switched ON (engine off or on).
Fail-safe	Not applicable
Possible cause	• DTCs are stored in the PCM. • Battery malfunction • Generator malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **10 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 6.
2	**VERIFY PCM DTCs** • Retrieve the PCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
3	**INSPECT BATTERY** • Inspect the battery. (See BATTERY INSPECTION.) • Is the battery normal?	Yes	Go to the next step.
		No	Replace the battery, then go to Step 5. (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
4	**INSPECT GENERATOR** • Inspect the generator. (See GENERATOR INSPECTION [WITHOUT i-ELOOP (SKYACTIV-G 1.3, SKYACTIV-G 1.5)].) (See GENERATOR INSPECTION [WITHOUT i-ELOOP (SKYACTIV-D 1.5)].) • Is the generator normal?	Yes	Go to the next step.
		No	Replace the generator, then go to the next step. (See GENERATOR REMOVAL/INSTALLATION [WITHOUT i-ELOOP (SKYACTIV-G 1.3, SKYACTIV-G 1.5)].) (See GENERATOR REMOVAL/INSTALLATION [WITHOUT i-ELOOP (SKYACTIV-D 1.5)].)
5	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **10 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the BCM. (See BODY CONTROL MODULE (BCM) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
6	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.

With i-ELOOP

Description	BCM power supply voltage high input
Detection condition	• The BCM detected the BCM power supply circuit (terminals 1A or 1B) voltage of **16 V or more** for **10 s or more** with the ignition switched ON (engine off or on).

Description	BCM power supply voltage high input
Fail-safe	Not applicable
Possible cause	• DTCs are stored in the PCM. • DTCs are stored in the DC-DC converter (i-ELOOP). • DC-DC converter (i-ELOOP) malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **10 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 6.
2	**VERIFY PCM DTCs** • Retrieve the PCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
3	**VERIFY DC-DC CONVERTER (i-ELOOP) DTCs** • Retrieve the DC-DC converter (i-ELOOP) DTCs using the M-MDS. (See DTC INSPECTION [i-ELOOP].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [i-ELOOP].)
		No	Go to the next step.
4	**INSPECT DC-DC CONVERTER (i-ELOOP)** • Inspect the DC-DC converter (i-ELOOP). (See DC-DC CONVERTER (i-ELOOP) INSPECTION [i-ELOOP].) • Is the DC-DC converter (i-ELOOP) normal?	Yes	Go to the next step.
		No	Replace the DC-DC converter (i-ELOOP), then go to the next step. (See DC-DC CONVERTER (i-ELOOP) REMOVAL/ INSTALLATION [WITH i-ELOOP (SKYACTIV-G 1.3, SKYACTIV-G 1.5)].) (See DC-DC CONVERTER (i-ELOOP) REMOVAL/ INSTALLATION [WITH i-ELOOP (SKYACTIV-D 1.5)].)
5	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Switch the ignition ON (engine off or on) and wait for **10 s or more**. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.
6	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.