ACTIVE COMMAND MODES TABLE [BCM]

id0902f5200200

Note
- Simulation items on parts which are not equipped to the vehicle do not operate.

Simulation item	Unit/ Operation	Data contents	Output part name	Operation condition
BG_HORN_RLY	If an accessory part is installed, it cannot be used.			
BLWR_RLY	Off/On	• Off: Turns the blower relay off. • On: Turns the blower relay on.	Blower relay	Ignition switched ON (engine off or on)
DR_LK_RY	Off/On	**Note** • The BCM sends a door lock relay operation request signal (lock signal) to the ESU via LIN communication. • Off: Does not lock the door. • On: Locks the door.	Door lock relay	Ignition switched ON (engine off or on)
DR_UNLK_RY	Off/On	**Note** • The BCM sends a door unlock relay operation request signal (unlock signal) to the ESU via LIN communication. • Off: Does not unlock the door. • On: Unlocks the door.	Door unlock relay	Ignition switched ON (engine off or on)
F_FOG_RELAY	Off/On	• Off: Turns the front fog light off. • On: Turns the front fog light on.	Front fog light relay	Ignition switched ON (engine off or on)
H/L_CLN_RY	Off/On	• Off: Turns the headlight cleaner relay off. • On: Turns the headlight cleaner relay on.	Headlight cleaner relay	Ignition switched ON (engine off or on)
H/L_DRL	Off/On	**Note** • The BCM sends a running light on request signal to the ESU via LIN communication. • Off: The running lights are turned off. • On: The running lights are turned on.	Running light	Ignition switched ON (engine off or on)
H/L_HI	0%/100%	**Note** • The BCM sends a headlight HI on request signal to the ESU via LIN communication. • 0%: The headlights HI are turned off. • 100%: The headlights HI are turned on.	Headlight HI	Ignition switched ON (engine off or on)
H/L_LOW	0%/100%	**Note** • The BCM sends a headlight LO on request signal to the ESU via LIN communication. • 0%: The headlights LO are turned off. • 100%: The headlights LO are turned on.	Headlight LO	Ignition switched ON (engine off or on)

Simulation item	Unit/ Operation	Data contents	Output part name	Operation condition
H/L_TNS	Off/Right-On/Left-On/ On	**Note** • The BCM sends a TNS on request signal to the ESU via LIN communication. • Off: Turns the parking lights off. • Right-On: Turns the parking light (RH) on. • Left-On: Turns the parking light (LH) on. • On: Turns the parking lights (RH/LH) on.	Parking light	Ignition switched ON (engine off or on)
HORN_RLY	Off/On	• Off: Stops the horn. • On: Sounds the horn.	Horn relay	Ignition switched ON (engine off or on)
PTC_HEAT_ST	0%/10%/ 20%/30%/ 40%/50%/ 60%/70%/ 80%	• 0%: Stops PTC heater output. • 10%: Controls PTC heater output level to 10%. • 20%: Controls PTC heater output level to 20%. • 30%: Controls PTC heater output level to 30%. • 40%: Controls PTC heater output level to 40%. • 50%: Controls PTC heater output level to 50%. • 60%: Controls PTC heater output level to 60%. • 70%: Controls PTC heater output level to 70%. • 80%: Controls PTC heater output level to 80%.	PTC heater	Ignition switched ON (engine off or on)
R_DEF_RLY	Off/On	• Off: Stops the rear window defogger. • On: Operates the rear window defogger.	Rear window defogger relay	Ignition switched ON (engine off or on)
R_FOG_LAMP	Off/On	• Off: Turns the rear fog light off. • On: Turns the rear fog light on.	Rear fog light relay	Ignition switched ON (engine off or on)
REVERSE_LMP	Off/On	**Note** • The BCM sends a back-up light on request signal to the ESU via LIN communication. • Off: Turns the back-up light off. • On: Turns the back-up light on.	Back-up light	Ignition switched ON (engine off or on)
ROOM_LAMP	Off/100% _On	**Note** • The BCM sends a front map light on request signal to the ESU via LIN communication. • Off: Turns the front map light off. • 100%_On: Turn the front map light on.	Front map light	Ignition switched ON (engine off or on)
STOP_LMP_CTL	Off/On	• Off: Turns the brake light off. • On: Turns the brake light on.	Brake light relay	Ignition switched ON (engine off or on)
TRUNK_LAMP	Off/On	**Note** • The BCM sends a cargo compartment light on request signal to the ESU via LIN communication. • Off: Turns the cargo compartment light off. • On: Turns the cargo compartment light on.	Cargo compartment light	Ignition switched ON (engine off or on)

Simulation item	Unit/ Operation	Data contents	Output part name	Operation condition
TRUNK_MOTOR	Off/On	**Note** • The BCM sends a liftgate release signal to the ESU via LIN communication. • Off: Does not open the liftgate. • On: Opens the liftgate.	Liftgate release relay	Ignition switched ON (engine off or on)
WASHER_CTRL	Off/ Front_ON	**Note** • The BCM sends a front washer operation request signal to the ESU via LIN communication. • Off: Stops the windshield washer motor. • Front_ON: Operates the windshield washer motor.	Windshield washer motor	Ignition switched ON (engine off or on)
WIP_R_CTRL	Off/INT/On/ On_1Time/ On_2Time/ On_3Time/ On_4Time	**Note** • The BCM sends a rear wiper operation request signal or rear wiper INT operation request signal to the ESU via LIN communication. • Off: Stops the rear wiper. • INT: Operates the rear wiper intermittently. • On: Operates the rear wiper continuously. • On_1Time: — • On_2Time: Operates the rear wiper twice. • On_3Time: — • On_4Time: —	Rear wiper motor	Ignition switched ON (engine off or on)