DTC B109F:49 [BCM]

id0902f5412600

Description	Intruder sensor internal malfunction
Detection condition	• BCM detects the intruder sensor internal malfunction for **1.5 s or more**.
Fail-safe	Not applicable
Possible cause	• Intruder sensor malfunction • BCM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY BCM DTCs AGAIN** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Lock the door to go on theft-deterrent system standby. • Unlock the door to cancel theft-deterrent system standby. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 4.
2	**INSPECT INTRUDER SENSOR** • Inspect the intruder sensor. (See INTRUDER SENSOR INSPECTION.) • Is the intruder sensor normal?	Yes	Go to the next step.
		No	Replace the intruder sensor, then go to the next step. (See INTRUDER SENSOR REMOVAL/INSTALLATION.)
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the BCM using the M-MDS. (See CLEARING DTC [BCM].) • Lock the door to go on theft-deterrent system standby. • Unlock the door to cancel theft-deterrent system standby. • Retrieve the BCM DTCs using the M-MDS. (See DTC INSPECTION [BCM].) • Is the same DTC displayed?	Yes	Replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BCM].)
		No	DTC troubleshooting completed.