DTC TABLE [ELECTRICAL SUPPLY UNIT (ESU)]

id0902ff060600

×: Applicable
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B1098:11	—	Parking light (LH) or taillight (RH) circuit malfunction	—	—	C	×	(See DTC B1098:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1099:11	—	Parking light (RH), taillight (LH), or license plate light (LH)/(RH) circuit malfunction	—	—	C	×	(See DTC B1099:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B111E:12	—	**4SD** • Trunk compartment light circuit malfunction **5HB** • Cargo compartment light circuit malfunction	—	—	C	×	(See DTC B111E:12 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1142:13	—	Ignition switch status mismatch	—	—	C	×	(See DTC B1142:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1207:09*2	—	Error signal received from SAS control module	—	—	C	×	(See DTC B1207:09 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1207:86*2	—	Error signal received from SAS control module	—	—	C	×	(See DTC B1207:86 [ELECTRICAL SUPPLY UNIT (ESU)].)
B124A:11*3	—	Running light circuit malfunction	—	—	C	×	(See DTC B124A:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1277:11	—	Back-up light circuit malfunction	—	—	C	×	(See DTC B1277:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1313:12	—	Front map light circuit malfunction	—	—	C	×	(See DTC B1313:12 [ELECTRICAL SUPPLY UNIT (ESU)].)
B143A:00*2	—	Collision detection unlock function operation	—	—	C	×	(See DTC B143A:00 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1A79:11*4	—	Rear fog light circuit malfunction	—	—	C	×	(See DTC B1A79:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1A79:13*4	—	Rear fog light circuit malfunction	—	—	C	×	(See DTC B1A79:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1C79:13	—	Washer motor circuit malfunction	—	—	C	×	(See DTC B1C79:13 [ELECTRICAL SUPPLY UNIT (ESU)].)

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B1D00:11	—	Headlight LO (LH) circuit malfunction	—	—	C	×	(See DTC B1D00:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D00:13	—	Headlight LO (LH) circuit malfunction	—	—	C	×	(See DTC B1D00:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D01:11	—	Headlight LO (RH) circuit malfunction	—	—	C	×	(See DTC B1D01:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D01:13	—	Headlight LO (RH) circuit malfunction	—	—	C	×	(See DTC B1D01:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D02:11	—	Headlight HI (LH) circuit malfunction	—	—	C	×	(See DTC B1D02:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D02:13	—	Headlight HI (LH) circuit malfunction	—	—	C	×	(See DTC B1D02:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D03:11	—	Headlight HI (RH) circuit malfunction	—	—	C	×	(See DTC B1D03:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D03:13	—	Headlight HI (RH) circuit malfunction	—	—	C	×	(See DTC B1D03:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D39:11	—	Rear wiper motor circuit malfunction	—	—	C	×	(See DTC B1D39:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
B1D39:13	—	Rear wiper motor circuit malfunction	—	—	C	×	(See DTC B1D39:13 [ELECTRICAL SUPPLY UNIT (ESU)].)
P0604:49	—	Electrical supply unit (ESU) internal malfunction	×	—	C	×	(See DTC P0604:49 [ELECTRICAL SUPPLY UNIT (ESU)].)
P0605:49	—	Electrical supply unit (ESU) internal malfunction	×	—	C	×	(See DTC P0605:49 [ELECTRICAL SUPPLY UNIT (ESU)].)
U0140:00	—	Communication error with BCM	×	—	C	×	(See DTC U0140:00 [ELECTRICAL SUPPLY UNIT (ESU)].)
U0322:09	—	Error signal received from BCM	×	—	C	×	(See DTC U0322:09 [ELECTRICAL SUPPLY UNIT (ESU)].)
U0322:82	—	Error signal received from BCM	×	—	C	×	(See DTC U0322:82 [ELECTRICAL SUPPLY UNIT (ESU)].)

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U0422:86	—	Error signal received from BCM	×	—	C	×	(See DTC U0422:86 [ELECTRICAL SUPPLY UNIT (ESU)].)
U2010:11	—	Illumination output circuit malfunction	—	—	C	×	(See DTC U2010:11 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3000:09	—	Electrical supply unit (ESU) internal malfunction	—	—	C	×	(See DTC U3000:09 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3000:44	—	Electrical supply unit (ESU) internal malfunction	×	—	C	×	(See DTC U3000:44 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3000:47	—	Electrical supply unit (ESU) internal malfunction	—	—	C	×	(See DTC U3000:47 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3000:49	—	Electrical supply unit (ESU) internal malfunction	—	—	C	×	(See DTC U3000:49 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3003:16	—	Electrical supply unit (ESU) power supply voltage low input	—	—	C	×	(See DTC U3003:16 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3003:17	—	Electrical supply unit (ESU) power supply voltage high input	—	—	C	×	(See DTC U3003:17 [ELECTRICAL SUPPLY UNIT (ESU)].)
U3006:16	—	Electrical supply unit (ESU) power supply voltage low input	—	—	C	×	(See DTC U3006:16 [ELECTRICAL SUPPLY UNIT (ESU)].)

*1 : C: CMDTC self test, D: ODDTC self test
*2 : With collision detection unlock function
*3 : With running light system
*4 : With rear fog light system