DTC U3000:49 [ELECTRICAL SUPPLY UNIT (ESU)]

id0902ff063600

Description	Electrical supply unit (ESU) internal malfunction
Detection condition	• RAM/ROM/ALU/TIMER malfunction in the electrical supply unit (ESU) is detected.
Fail-safe	Not applicable
Possible cause	• Electrical supply unit (ESU) internal malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS ELECTRICAL SUPPLY UNIT (ESU) DEPENDING ON REPEATABILITY** • Clear the DTC for the electrical supply unit (ESU) using the M-MDS. (See CLEARING DTC [ELECTRICAL SUPPLY UNIT (ESU)].) • Retrieve the electrical supply unit (ESU) DTCs using the M-MDS. (See DTC INSPECTION [ELECTRICAL SUPPLY UNIT (ESU)].) • Is the same DTC displayed?	Yes	Replace the electrical supply unit (ESU), then go to the next step. (See ELECTRICAL SUPPLY UNIT (ESU) REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRICAL SUPPLY UNIT (ESU)].)
		No	DTC troubleshooting completed.