	• RAM malfunction in electrical supplC unit (ESU) detected.
Fail-safe	**Exterior lighting system** When the ignition is switched ON (engine off or on), the headlights LO, TNS, and panel light turn on and other exterior light controls are stopped. **Interior light control system**