DTC U2300:54 [HEADLIGHT AUTO LEVELING SYSTEM]

id0902i7017800

Description	Error configuration data received from instrument cluster
Detection condition	• Auto leveling control module received the error configuration data from the instrument cluster for **30 s or more** with the ignition switched ON (engine off or on).
Fail-safe	• Control of the headlight auto leveling system is continued.
Possible cause	• DTCs are stored in the instrument cluster. — Instrument cluster configuration not implemented — Instrument cluster internal memory malfunction • Instrument cluster configuration data error • Auto leveling control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY INSTRUMENT CLUSTER DTCs** • Retrieve the instrument cluster DTCs using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
2	**RESET INSTRUMENT CLUSTER CONFIGURATION DATA** • Using the M-MDS, perform the instrument cluster configuration (using As-Built data). (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) • Clear the DTC for the auto leveling control module using the M-MDS. (See CLEARING DTC [HEADLIGHT AUTO LEVELING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for **30 s or more**. • Retrieve the auto leveling control module DTCs using the M-MDS. (See DTC INSPECTION [HEADLIGHT AUTO LEVELING SYSTEM].) • Is the same DTC displayed?	Yes	Using the M-MDS, perform the instrument cluster configuration (using As-Built data) again, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)
		No	Go to Step 4.
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the auto leveling control module using the M-MDS. (See CLEARING DTC [HEADLIGHT AUTO LEVELING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for **30 s or more**. • Retrieve the auto leveling control module DTCs using the M-MDS. (See DTC INSPECTION [HEADLIGHT AUTO LEVELING SYSTEM].) • Is the same DTC displayed?	Yes	Replace the auto leveling control module, then go to the next step. (See AUTO LEVELING CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [HEADLIGHT AUTO LEVELING SYSTEM].)
		No	DTC troubleshooting completed.