DTC B1041:54 [HEADLIGHT AUTO LEVELING SYSTEM]

id0902i7934000

Description	Headlight auto leveling system initialization error
Detection condition	• Headlight auto leveling system initialization is not performed with the ignition switched ON (engine off or on).
Fail-safe	• The headlight leveling actuator is stopped at the position when the malfunction is determined.
Possible cause	• Headlight auto leveling system initialization is not performed. • Auto leveling control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**PERFORM HEADLIGHT AUTO LEVELING SYSTEM INITIALIZATION** • Perform the headlight auto leveling system initialization. (See HEADLIGHT AUTO LEVELING SYSTEM INITIALIZATION.) • Clear the DTC for the auto leveling control module using the M-MDS. (See CLEARING DTC [HEADLIGHT AUTO LEVELING SYSTEM].) • Retrieve the auto leveling control module DTCs. (See DTC INSPECTION [HEADLIGHT AUTO LEVELING SYSTEM].) • Is the same DTC displayed?	Yes	Perform the headlight auto leveling system initialization again, then go to the next step. (See HEADLIGHT AUTO LEVELING SYSTEM INITIALIZATION.)
		No	Go to Step 3.
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the auto leveling control module using the M-MDS. (See CLEARING DTC [HEADLIGHT AUTO LEVELING SYSTEM].) • Retrieve the auto leveling control module DTCs. (See DTC INSPECTION [HEADLIGHT AUTO LEVELING SYSTEM].) • Is the same DTC displayed?	Yes	Replace the auto leveling control module, then go to the next step. (See AUTO LEVELING CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [HEADLIGHT AUTO LEVELING SYSTEM].)
		No	DTC troubleshooting completed.