DIAGNOSTIC ASSIST FUNCTION [CONNECTIVITY MASTER UNIT]

id0902n7039300

Activation Procedure
Using commander switch
1. Switch che nition .3(c)6(o)1.9(ACC)-6(or)-5.4( )-7ON (engine off or on).

Diagnostic Assist Code Input Procedure

Note

- If [- REJECTED] is displayed, the inspection cann

No.	Center display (diagnostic content)

Inspection