DTC B1D19:64 [CONNECTIVITY MASTER UNIT]

id0902n7091100

Description	Incompatible disc inserted
Detection condition	• With the ignition switched ON (engine on or off), the connectivity master unit (CMU) detects a disc having a data format that is incompatible with the CD player or DVD/CD player.
Fail-safe	Eject a disc.
Possible cause	• Disc malfunction or malfunction due to customer use method — Use of incompatible disc • Data format other than music data (CD-DA)/MP3/WMA (Windows Media Audio)/AAC (Advance Audio Coding) is stored in the disc. (With CD player) • Data format other than music data (CD-DA)/MP3/WMA (Windows Media Audio)/AAC (Advance Audio Coding)/DVD VIDEO/DVD-VR is stored in the disc. (With DVD/CD player) — Use of blank disc — Disc insertion direction mistaken — Disc scratched or dirty • CD player or DVD/CD player internal malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS DISC** • After obtaining the customer's consent, insert a disc that was not used when the malfunction occurred into the CD player or DVD/CD player. • Does the disc play normally?	Yes	System is normal. (Explain to the customer that there is a malfunction in the disc or malfunction due to the customer use method.)
		No	Go to the next step.
2	**VERIFY IF MALFUNCTIONING LOCATION IS CD PLAYER OR DVD/CD PLAYER DEPENDING ON REPEATABILITY** • Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].) • Perform diagnostic assist code “01” CD player or DVD/CD player inspection. (See DIAGNOSTIC ASSIST FUNCTION [CONNECTIVITY MASTER UNIT].) • Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].) • Is the same DTC displayed?	Yes	Replace the CD player or DVD/CD player, then go to the next step. (See CD PLAYER REMOVAL.) (See CD PLAYER INSTALLATION.) (See DVD/CD PLAYER REMOVAL.) (See DVD/CD PLAYER INSTALLATION.)
		No	Go to the next step.
3	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [CONNECTIVITY MASTER UNIT].)
		No	DTC troubleshooting completed.