DTC B1D19:98 [CONNECTIVITY MASTER UNIT]

id0902n7091200

Description	Abnormal CD player or DVD/CD player temperature
Detection condition	• With the ignition switched ON (engine off or on), the connectivity master unit (CMU) detects an abnormally high temperature condition in the CD player or DVD/CD player.
Fail-safe	CD/DVD playback stopped.
Possible cause	**Caution** **• If the CD player or DVD/CD player is used for long periods in a hot environment, the temperature of the CD player or DVD/CD player will increase and a DTC may be output. The CD player or DVD/CD player should not be used continuously for long periods with the cabin under high temperature conditions from being left under direct sunlight.** • Temperature increase due to continuous use for long periods. • CD player or DVD/CD player malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF CD PLAYER OR DVD/CD PLAYER TEMPERATURE WAS TEMPORARILY HIGH** • Leave the vehicle in a cool location for **30 min** or more • Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].) • Switch the ignition ON (engine off or on) and wait for **7 s or more**. • Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 3.
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].) • Switch the ignition ON (engine off or on) and wait for **7 s or more**. • Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].) • Is the same DTC displayed?	Yes	Replace the CD player or DVD/CD player, then go to the next step. (See CD PLAYER REMOVAL.) (See CD PLAYER INSTALLATION.) (See DVD/CD PLAYER REMOVAL.) (See DVD/CD PLAYER INSTALLATION.)
		No	Go to the next step.
3	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [CONNECTIVITY MASTER UNIT].)
		No	DTC troubleshooting completed.