DTC U0028:88 [CONNECTIVITY MASTER UNIT]

id0902n7106300

Description	Unit communication error (LOCAL-CAN)
Detection condition	• The connectivity master unit (CMU) detects CAN bus communication line (LOCAL-CAN) malfunction **10 times** continuously.
Fail-safe	• Not applicable
Possible cause	• Malfunction in CAN bus communication line • Connectivity master unit (CMU) malfunction — Malfunction in CAN bus communication line
System wiring diagram	• Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF OTHER DTCs DISPLAYED FOR CONNECTIVITY MASTER UNIT (CMU)** • Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].) • Switch the ignition ON (engine off or on) and wait for **7 s or more**. • Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].) • Is DTC U00184:00 or U0187:00 displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [CONNECTIVITY MASTER UNIT].)
		No	Go to the next step.
2	**VERIFY IF MALFUNCTIONING LOCATION IS CONNECTIVITY MASTER UNIT (CMU) DEPENDING ON REPEATABILITY** • Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].) • Switch the ignition ON (engine off or on) and wait for **7 s or more**. • Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].) • Is the same DTC displayed?	Yes	Replace the connectivity master unit (CMU), then go to the next step. (See CONNECTIVITY MASTER UNIT (CMU) REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [CONNECTIVITY MASTER UNIT].)
		No	DTC troubleshooting completed.