## DTC U2300:55 [CONNECTIVITY MASTER UNIT]

id0902n7106600

| Description | Instrument cluster configuration not implemented |
|---|---|
| Detection condition | • The connectivity master unit (CMU) detected any of the following conditions with the ignition switched to ACC or ON (engine off or on).<br>— Instrument cluster configuration not read<br>— Configuration data cannot be written to connectivity master unit (CMU) memory. |
| Fail-safe | Not applicable |
| Possible cause | **Note**<br>• To correctly write the configuration data, which is sent from the instrument cluster to the connectivity master unit (CMU), to the connectivity master unit (CMU), **3 s or more** must have elapsed since the ignition was switched ON (engine off or on).<br><br>• Instrument cluster configuration is not completed.<br>• Connectivity master unit (CMU) malfunction |
| System wiring diagram | Not applicable |

### Diagnostic Procedure

| Step | Inspection | | Action |
|---|---|---|---|
| 1 | **RESET CONFIGURATION DATA FROM INSTRUMENT CLUSTER TO CONNECTIVITY MASTER UNIT (CMU)**<br>• Using the M-MDS, perform the instrument cluster configuration with the As-Built data. (See INSTRUMENT CLUSTER CONFIGURATION (USING READ/WRITE FUNCTION).)<br>• Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].)<br>• Switch the ignition ON (engine off or on) and wait for **10 s or more**.<br>• Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].)<br>• Is the same DTC displayed? | Yes | Using the M-MDS, re-perform the instrument cluster configuration using the As-Built data, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) |
| | | No | Go to Step 3 |
| 2 | **VERIFY THAT REPAIRS HAVE BEEN COMPLETED**<br>• Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].)<br>• Switch the ignition ON (engine off or on) and wait for **10 s or more**.<br>• Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].)<br>• Is the same DTC displayed? | Yes | Replace the connectivity master unit (CMU), then go to the next step. (See CONNECTIVITY MASTER UNIT (CMU) REMOVAL/INSTALLATION.) |
| | | No | Go to the next step. |
| 3 | **VERIFY IF OTHER DTCs DISPLAYED**<br>• Are any other DTCs displayed? | Yes | Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [CONNECTIVITY MASTER UNIT].) |
| | | No | DTC troubleshooting completed. |